

CONTROLLED ENVIRONMENTS

Critical Environments

Models 8636
8636-BAC
SUREFLOW™
Room Pressure Controller

Operation and Service Manual

P/N 1980441, Revision G
March 2011



TRUST. SCIENCE. INNOVATION.

**Models 8636
8636-BAC
SUREFLOW™
Room Pressure Controller**

Operation and Service Manual

P/N 1980441, Revision G
March 2011

U.S. AND CANADA

Sales & Customer Service:
(800) 874-2811/(651) 490-2811
Fax:
(651) 490-3824

TSI Incorporated
ATTN: Customer Service
500 Cardigan Road
Shoreview, MN 55126
USA

OTHER COUNTRIES

Sales & Customer Service:
(001 651) 490-2811
Fax:
(001 651) 490-3824

E-MAIL

answers@tsi.com

WEB SITE

www.tsi.com



Copyright ©- TSI Incorporated / March 2011 / All rights reserved.

Part Number 1980441 Revision G

LIMITATION OF WARRANTY AND LIABILITY (effective July 2000)

Seller warrants the goods sold hereunder, under normal use and service as described in the operator's manual, shall be free from defects in workmanship and material for twenty-four (24) months, or the length of time specified in the operator's manual, from the date of shipment to the customer. This warranty period is inclusive of any statutory warranty. This limited warranty is subject to the following exclusions:

- a. Hot-wire or hot-film sensors used with research anemometers, and certain other components when indicated in specifications, are warranted for 90 days from the date of shipment.
- b. Parts repaired or replaced as a result of repair services are warranted to be free from defects in workmanship and material, under normal use, for 90 days from the date of shipment.
- c. Seller does not provide any warranty on finished goods manufactured by others or on any fuses, batteries or other consumable materials. Only the original manufacturer's warranty applies.
- d. Unless specifically authorized in a separate writing by Seller, Seller makes no warranty with respect to, and shall have no liability in connection with, goods which are incorporated into other products or equipment, or which are modified by any person other than Seller.

The foregoing is IN LIEU OF all other warranties and is subject to the LIMITATIONS stated herein. **NO OTHER EXPRESS OR IMPLIED WARRANTY OF FITNESS FOR PARTICULAR PURPOSE OR MERCHANTABILITY IS MADE.**

TO THE EXTENT PERMITTED BY LAW, THE EXCLUSIVE REMEDY OF THE USER OR BUYER, AND THE LIMIT OF SELLER'S LIABILITY FOR ANY AND ALL LOSSES, INJURIES, OR DAMAGES CONCERNING THE GOODS (INCLUDING CLAIMS BASED ON CONTRACT, NEGLIGENCE, TORT, STRICT LIABILITY OR OTHERWISE) SHALL BE THE RETURN OF GOODS TO SELLER AND THE REFUND OF THE PURCHASE PRICE, OR, AT THE OPTION OF SELLER, THE REPAIR OR REPLACEMENT OF THE GOODS. IN NO EVENT SHALL SELLER BE LIABLE FOR ANY SPECIAL, CONSEQUENTIAL OR INCIDENTAL DAMAGES. SELLER SHALL NOT BE RESPONSIBLE FOR INSTALLATION, DISMANTLING OR REINSTALLATION COSTS OR CHARGES. No Action, regardless of form, may be brought against Seller more than 12 months after a cause of action has accrued. The goods returned under warranty to Seller's factory shall be at Buyer's risk of loss, and will be returned, if at all, at Seller's risk of loss.

Buyer and all users are deemed to have accepted this LIMITATION OF WARRANTY AND LIABILITY, which contains the complete and exclusive limited warranty of Seller. This LIMITATION OF WARRANTY AND LIABILITY may not be amended, modified or its terms waived, except by writing signed by an Officer of Seller.

SERVICE POLICY

Knowing that inoperative or defective instruments are as detrimental to TSI as they are to our customers, our service policy is designed to give prompt attention to any problems. If any malfunction is discovered, please contact your nearest sales office or representative, or call TSI's Customer Service department at (651) 490-2811 or (800) 874-2811.

TRADEMARKS

TSI, TSI logo, and SUREFLOW™ are trademarks of TSI Incorporated.

BACnet is a registered trademark of ASHRAE.

LonWorks is a registered trademark of Echelon® Corporation.

Microsoft is a registered trademark of Microsoft Corporation.

CONTENTS

HOW TO USE THIS MANUAL	III
PART ONE.....	1
User Basics	1
The Instrument	1
Operator Panel.....	3
Alarms	5
Before Calling TSI.....	6
PART TWO	7
Technical Section.....	7
Software Programming	8
Menu and Menu Items	12
Calibration	39
Maintenance and Repair Parts	43
Troubleshooting Section	45
APPENDIX A	55
Specifications	55
APPENDIX B	57
Network Communications	57
Modbus Communications	57
LonWorks® Node Object.....	61
LonWorks® Object.....	62
8636 BACnet® MS/TP Protocol Implementation Conformance Statement.....	64
Model 8636-BAC BACnet® MS/TP Object Set	66
APPENDIX C	69
Wiring Information	69
APPENDIX D	71
Access Codes	71

How to Use This Manual

The SUREFLOW™ Operation and Service Manual is divided into two parts. [Part one](#) describes how the SUREFLOW™ unit functions and how to interface with the device. This section should be read by users, facilities staff, and anyone who requires a basic understanding of how the SUREFLOW™ controller operates.

Part two describes the technical aspects of the product which includes operation, calibration, configuration, maintenance, and troubleshooting. [Part two](#) should be read by personnel programming or maintaining the unit. TSI recommends thoroughly reading this manual before changing any software items.

NOTE: This operation and service manual assumes proper SUREFLOW™ controller installation. Refer to the Installation Instructions to determine if the SUREFLOW™ controller has been properly installed.

(This page intentionally left blank)

PART ONE

User Basics

Reading product manuals should not be a difficult and time-consuming process. This section provides a brief but thorough overview of the SUREFLOW™ product by maximizing information with minimal reading. These few pages explain the purpose (The Instrument), and the operation (Useful User Information, Digital Interface Module, Alarms) of the unit. Technical product information is available in [Part Two](#) of the manual. The manual focuses on laboratory spaces, but the product information is accurate for any room pressure application.

The Instrument

SUREFLOW™ controller measures and reports “room pressure.” Proper room pressure can control airborne contaminants that can adversely affect experiments, workers in the laboratory, and people in the laboratory vicinity. For example, laboratories with fume hoods need negative room pressure (air flowing into the room), to minimize exposure to people outside the laboratory. The fume hood is the first level of containment, and the laboratory itself is the second level of containment.

Room pressure, or pressure differential, is created when one space (hallway) is at a different pressure than an adjoining space (laboratory). When a pressure differential is created between two spaces, air is forced to flow from the higher pressure space to the lower pressure space. The direction of air flow is one component of proper room pressure. The second component of room pressure is the speed or how fast is the air moving between the two spaces. The SUREFLOW™ controller provides both pieces of information by measuring whether the air is flowing into or out of a laboratory, and the speed of the air.

Negative room pressure is present when air flows from a hallway into the laboratory. If air flows from the laboratory into the hallway the room is under positive pressure. Figure 1 gives a graphic example of positive and negative room pressure.




Figure 1: Room Pressure

An example of negative pressure is a bathroom with an exhaust fan. When the fan is turned on, air is exhausted out of the bathroom creating a slight negative pressure when compared to the hallway. This pressure differential forces air to flow from the hallway into the bathroom.

The SUREFLOW™ device informs the laboratory users when the laboratory is under proper pressure, and provides alarms when the room pressure is inadequate. If the room pressure is in the safe range, a green light is on. If the pressure is inadequate, a red alarm light and audible alarm turn on.

The SUREFLOW™ controller consists of two pieces: a pressure sensor and a Digital Interface Module (DIM). The pressure sensor is mounted above the doorway entrance to the laboratory. Usually the DIM is mounted close to the entrance to the laboratory. The pressure sensor continuously measures the room pressure and provides room pressure information to the DIM. The DIM continuously reports the room pressure and activates the alarms when necessary. SUREFLOW™ controller is a continuous measuring system providing instant information on the room pressure.

Useful User Information

The DIM has a green light and red light to indicate room pressure status. The green light is on when the room has proper room pressure. The red light comes on when an alarm condition exists.

Sliding the door panel to the right reveals a digital display and keypad (Figure 2). The display shows detailed information about room pressure, alarms, etc. The keypad allows you to test the device, put the device into emergency mode, and program or change the device parameters.




Figure 2: Digital Interface Module (DIM)

SUREFLOW™ controller has two levels of user information:

1. SUREFLOW™ controller has a red light and green light to provide continuous information on room pressure status.
2. SUREFLOW™ controller has a hidden operator panel providing detailed room status information, self-testing capabilities, and access to the software programming functions.

NOTE: The unit provides continuous room pressure status through the red and green light. The operator panel is normally closed unless further information on room pressure status is needed, or software programming is required.

User Keys—Gray with Black Letters

The four keys with black letters provide you information without changing the operation or the function of the unit.

TEST Key

The **TEST** key initiates an instrument self-test. Pressing the **TEST** key activates a scrolling sequence on the display that shows the product model number, software version, and all setpoint and alarm values. The unit then performs a self test that tests the display, indicator lights, audible alarm, and internal electronics to ensure they are operating properly. If a problem with the unit exists, **DATA ERROR** will be displayed. You should have qualified personnel determine the problem with the unit.

RESET Key

The **RESET** key performs three functions.

- 1) Resets the alarm light, alarm contacts, and audible alarm when in a latched or nonautomatic reset mode. The room pressure must be in the safe or normal range before the **RESET** key will operate.
- 2) Resets the emergency function after the emergency key has been pressed (see **EMERGENCY** key).
- 3) Clears any displayed error messages.

MUTE Key

The **MUTE** key temporarily silences the audible alarm. The time the alarm is temporarily silenced is programmable by you (see [MUTE TIMEOUT](#)). When the mute period ends, the audible alarm turns back on if the alarm condition is still present.

NOTE: You can program the audible alarm to be permanently turned off (see [AUDIBLE ALM](#)).

AUX Key

The **AUX** key is active only in specialty applications and is not used on the standard SUREFLOW™ controller. If the **AUX** key is used, a separate manual supplement will explain the **AUX** key function.

Programming Keys—Gray with Blue Characters

The four keys with blue print are used to program or configure the unit to fit a particular application.

WARNING: Pressing these keys will change how the unit functions, so please thoroughly review the manual before changing menu items.

MENU Key

The **MENU** key performs three functions.

- 1) Provides access to the menus when in the normal operating mode.
- 2) When the unit is being programmed, the **MENU** key acts as an escape key to remove you from an item or menu, without saving data.
- 3) Returns the unit to the normal operating mode. The **MENU** key is further described in the [Software Programming](#) section of this manual.

SELECT Key

The **SELECT** key performs three functions.

- 1) Provides access to specific menus.
- 2) Provides access to menu items.
- 3) Saves data. Pressing the key when finished with a menu item will save the data, and exit you out of the menu item.

▲/▼ Keys

The ▲/▼ keys are used to scroll through the menus, menu items, and through the range of item values that can be selected. Depending on the item type the values may be numerical, specific properties (on / off), or a bar graph.

Emergency Key—Red with Black Letters

EMERGENCY Key

The red **EMERGENCY** key puts the controller into emergency mode. If the room is under negative room pressure control, the emergency mode will maximize the negative pressure. Conversely, if the room is under positive room pressure control, the emergency mode will maximize the positive pressure.

Pressing the **EMERGENCY** key will cause the display to flash "EMERGENCY", the red alarm light to flash on and off, and the audible alarm to beep intermittently. To return to control mode press the **EMERGENCY** key or the **RESET** key.

Alarms

SUREFLOW™ controller has visual (red light) and audible alarms to inform you of changing conditions. The alarm levels (setpoints) are determined by administrative personnel, Industrial Hygienists, or the facilities group depending on the organization.

The alarms, audible and visual, will activate whenever the preset alarm level is reached. Depending on the SUREFLOW™ controller items installed, programmed alarms will activate when room pressure is low or inadequate, when room pressure is high or too great, or when the supply or exhaust air flow is insufficient. When the laboratory is operating safely, no alarms will sound.

Example: The low alarm is preset to activate when the room pressure reaches -0.001 inches H₂O. When the room pressure drops below -0.001 inches H₂O (gets closer to zero), the audible and visual alarms activate. The alarms turn off (when set to unlatched) when the unit returns to the safe range that is defined as negative pressure greater than -0.001 inches H₂O.

Visual Alarm Operation

The red light on the front of the unit indicates an alarm condition. The red light is on for all alarm conditions, low alarms, high alarms, and emergency. The light is on continuously in a low or high alarm condition, and flashes in an emergency condition.

Audible Alarm Operation- EMERGENCY key

When the **EMERGENCY** key is pressed, the audible alarm beeps intermittently until the **EMERGENCY** or **RESET** key is pressed terminating the emergency alarm. The emergency alarm cannot be silenced by pressing the **MUTE** key.

Audible Alarms - All Except Emergency

The audible alarm is continuously on in all low and high alarm conditions. The audible alarm can be temporarily silenced by pressing the **MUTE** key. The alarm will be silent for a period of time (see [MUTE TIMEOUT](#) to program time period). When the time out period ends, the audible alarm turns back on if the alarm condition is still present.

You can program the audible alarm to be permanently turned off (see [AUDIBLE ALM](#)). The red alarm light will still turn on in alarm conditions when audible alarm is turned off.

The audible and visual alarms can be programmed to either automatically turn off when the unit returns to the safe range or to stay in alarm until the **RESET** key is pressed (See [ALARM RESET](#)).

Before Calling TSI

This manual should answer most questions and resolve most problems you may encounter. If you need assistance or further explanation, contact your local TSI representative or TSI. TSI is committed to providing high quality products backed by outstanding service.

Please have the following information available prior to contacting your authorized TSI Manufacturer's Representative or TSI:

- Model number of unit* 8636- ____
- Software revision level*
- Facility where unit is installed

* First two items that scroll when **TEST** key is pressed

Due to the different SUREFLOW™ models available, the above information is needed to accurately answer your questions.

For the name of your local TSI representative or to talk to TSI service personnel, please call TSI at:

U.S. AND CANADA

Sales & Customer Service:
(800) 874-2811/(651) 490-2811
Fax:
(651) 490-3824

OTHER COUNTRIES

Sales & Customer Service:
(001 651) 490-2811
Fax:
(001 651) 490-3824

TSI Incorporated
ATTN: Customer Service
500 Cardigan Road
Shoreview, MN 55126
USA

E-MAIL
answers@tsi.com

WEB SITE
www.tsi.com

PART TWO

Technical Section

The SUREFLOW™ controller is ready to use after being properly installed. The pressure sensor is factory calibrated prior to shipping, and should not need adjustment. The Digital Interface Module (DIM) is programmed with a default configuration that can be easily modified to fit your application.

The Technical section is separated into five parts that cover all aspects of the unit. Each section is written as independently as possible to minimize flipping back and forth through the manual for an answer.

The [Software Programming](#) section explains the programming keys on the DIM. In addition, the programming sequence is described, which is the same regardless of the menu item being changed. At the end of this section is an example of how to program the DIM.

The [Menu and Menu Item](#) section lists all of the software items available to program and change. The items are grouped by menu which means all setpoints are in one menu, alarm items in another, etc. The menu items and all related information is listed in table format and includes programming name, description of menu of item, range of programmable values, and how the unit shipped from the factory (default values).

The [Calibration](#) section describes the required technique to compare the pressure sensor reading to a thermal anemometer, and how to adjust the zero and span to obtain an accurate calibration. This section also describes how to zero a TSI flow station transducer.

The [Maintenance and Repair Part](#) section covers all routine maintenance of equipment, along with a list of repair parts.

The [Troubleshooting](#) section is split into two areas: mechanical operation of the unit and system performance. Many external variables will affect how the unit functions so it is critical to first determine if the unit is having mechanical problems - i.e. no display on unit, remote alarms don't function, dampers don't modulate, etc. If problems still exist, look for performance problems (i.e., doesn't seem to read correctly, display fluctuates, etc.). The first step is to determine that the system is mechanically operating correctly, followed by modifying the configuration to eliminate the performance problems.

Software Programming

Programming the SUREFLOW™ controller is quick and easy if the programming keys are understood, and the proper keystroke procedure is followed. The programming keys are defined first, followed by the required keystroke procedure. At the end of this section is a programming example.

NOTE: The unit is always operating while programming unit (except when checking the control outputs). When a menu item value is changed, the new value takes effect **immediately** after saving the change.

NOTE: This section covers programming the instrument through the keypad and display. If programming through RS-485 communications, use the host computer's procedure. The changes take place immediately upon saving data in the instrument.

Programming Keys

The four keys with blue characters (refer to Figure 4) are used to program or configure the unit to fit your particular application. Programming the instrument will change how the unit functions, so thoroughly review the items to be changed.




Figure 4: Programming Keys

MENU Key

The **MENU** key has three functions.

1. The **MENU** key is used to gain access to the menus when the unit is in the normal operating mode. Pressing the key once will exit the normal operating mode and enter the programming mode. When the **MENU** key is first pressed, the first two menus are listed.
2. When the unit is being programmed, the **MENU** key acts like an escape key.
 - When scrolling through the main menu, pressing the **MENU** key will return the unit to standard operating mode.
 - When scrolling through the items on a menu, pressing the **MENU** key will return you to the list of menus.
 - When changing data in a menu item, pressing the **MENU** key will escape out of the item without saving changes.
3. When programming is complete, pressing the **MENU** key will return the unit to normal operating mode.

SELECT Key

The **SELECT** key has three functions.

1. The **SELECT** key is used to gain access to specific menus. To access a menu, scroll through the menus (using arrow keys) and place the flashing cursor on the desired menu. Press the **SELECT** key to select the menu. The first line on the display will now be the selected menu, and the second line will show the first menu item.
2. The **SELECT** key is used to gain access to specific menu items. To access a menu item scroll through the menu items until item appears. Press the **SELECT** key and the menu item will now appear on the first line of the display, and the second line will show the item value.
3. Pressing the **SELECT** key when finished changing an item will save the data, and exit back to the menu items. An audible tone (3 beeps) and visual display (“saving data”) gives confirmation data is being saved.

▲/▼ Keys

The ▲/▼ keys are used to scroll through the menus, menu items, and through the range of item values that can be selected. Depending on the menu item selected the value may be numerical, specific property (on/off), or a bar graph.

NOTE: When programming a menu item, continuously pressing the arrow key will scroll through the values faster than if arrow key is pressed and released.

Keystroke Procedure

The keystroke operation is consistent for all menus. The sequence of keystrokes to follow is the same regardless of the menu item being changed.

1. Press the **MENU** key to access the main menu.
2. Use the ▲/▼ keys to scroll through the menu choices. The blinking cursor needs to be on the first letter of the menu you want to access.
3. Press the **SELECT** key to access chosen menu.
4. The menu selected is now displayed on line one, and the first menu item is displayed on line 2. Use the ▲/▼ keys to scroll through the menu items. Scroll through the menu items until desired item is displayed.

NOTE: If “Enter Code” is flashing, the access code must be entered before you can enter the menu. Access codes are found in Appendix D.

5. Press the **SELECT** key to access chosen item. The top line of display shows menu item selected, while the second line shows current item value.
6. Use the ▲/▼ keys to change item value.
7. Save the new value by pressing the **SELECT** key (pressing the **MENU** key will exit out of menu function without saving data).
8. Press the **MENU** key to exit current menu, and return to main menu.
9. Press the **MENU** key again to return to normal instrument operation.

If more than one item is to be changed, skip steps 8 and 9 until all changes are complete. If more items in the same menu are to be changed, scroll to them after saving the data (step 7). If other

menus need to be accessed, press the **MENU** key once to access list of menus. The instrument is now at step 2 of the keystroke sequence.

Programming Example

The following example demonstrates the keystroke sequence explained above. In this example the high alarm setpoint will be changed from -0.002 inches H₂O to -0.003 inches H₂O.

- | | |
|---|---|
| <p>❶ Unit is in normal operation scrolling room pressure, flows, etc. Pressure is shown in this case:</p> | <div style="border: 1px solid black; padding: 2px; display: inline-block;">PRESSURE
-.00085" H₂O</div> |
| <p>❷ Press the MENU key to gain access to the menus.</p> | <div style="border: 1px solid black; padding: 2px; display: inline-block;">MENU</div> |
| <p>❸ Press the ▼ key once. Blinking cursor should be on A of Alarm. Press the SELECT key to access the ALARM menu.</p> <p style="margin-left: 40px;">NOTE: Blinking cursor must be on A in Alarm.</p> | <p>The first 2 menu choices are displayed.</p> <div style="border: 1px solid black; padding: 2px; display: inline-block;">SETPOINTS
ALARM</div> |
| <p>❹ Press the ▼ key until HIGH ALARM is shown on display.</p> | <div style="border: 1px solid black; padding: 2px; display: inline-block;">SELECT</div> |
| <p>❺ Press the SELECT key to access the high alarm setpoint. The item name (HIGH ALARM) will now be displayed on line 1, and the item's current value will be displayed on line 2.</p> | <p>Line 1 shows menu selected.
Line 2 shows first menu item.</p> <div style="border: 1px solid black; padding: 2px; display: inline-block;">ALARM
LOW ALARM</div> |
| <p>❻ Press the ▲ key to change the high alarm setpoint to - 0.003 inches H₂O.</p> | <p>Menu selected
Item name</p> <div style="border: 1px solid black; padding: 2px; display: inline-block;">▼</div> |
| <p>❼ Press the SELECT key to access the high alarm setpoint. The item name (HIGH ALARM) will now be displayed on line 1, and the item's current value will be displayed on line 2.</p> | <p>Item Name
Current Value</p> <div style="border: 1px solid black; padding: 2px; display: inline-block;">ALARM
HIGH ALARM</div> |
| <p>❽ Press the ▲ key to change the high alarm setpoint to - 0.003 inches H₂O.</p> | <div style="border: 1px solid black; padding: 2px; display: inline-block;">SELECT</div> |
| <p>❾ Press the ▲ key to change the high alarm setpoint to - 0.003 inches H₂O.</p> | <div style="border: 1px solid black; padding: 2px; display: inline-block;">HIGH ALARM
-.00200" H₂O</div> |
| <p>❿ Press the ▲ key to change the high alarm setpoint to - 0.003 inches H₂O.</p> | <div style="border: 1px solid black; padding: 2px; display: inline-block;">▲</div> |
| <p>⓫ Press the ▲ key to change the high alarm setpoint to - 0.003 inches H₂O.</p> | <div style="border: 1px solid black; padding: 2px; display: inline-block;">HIGH ALARM
- .00300" H₂O</div> |

- 7 Press the **SELECT** key to save the new negative low alarm setpoint.

SELECT

Three short beeps will sound indicating that the data is being saved.

HIGH ALARM
Saving Data

Immediately after the data is saved, the SUREFLOW™ controller will return to the menu level displaying the menu title on the top line of the display and the menu item on the bottom line (goes to step 3).

ALARM
HIGH ALARM

WARNING: If the **MENU** key was pressed instead of the **SELECT** key, the new data would not have been saved, and the SUREFLOW™ controller would have escaped back to the menu level shown in step 3.

- 8 Press the **MENU** key once to return to the menu level:

MENU

ALARM
CONFIGURE

- 9 Press the **MENU** key a second time to return to the normal operating level:

MENU

Unit is now back in normal operation

PRESSURE
-.00085" H₂O

Menu and Menu Items

The SUREFLOW™ controller is a very versatile device that can be configured to meet your specific application. This section describes all of the menu items available to program and change (except diagnostics menu). Changing any item is accomplished by using the keypad, or if communications are installed through the RS-485 Communications port. If you are unfamiliar with the keystroke procedure please see [Software Programming](#) for a detailed explanation. This section provides the following information:

- Complete list of menu and all menu items.
- Gives the menu or programming name.
- Defines each menu item's function; what it does, how it does it, etc.
- Gives the range of values that can be programmed.
- Gives default item value (how it shipped from factory).

The menus covered in this section are divided into groups of related items to ease programming. As an example all setpoints are in one menu, alarm information in another, etc. The manual follows the menus as programmed in the controller. The menu items are always grouped by menu and then listed in menu item order, not alphabetical order. Figure 5 shows a chart of all the Model 8636 controller menu items.

(continued on next page)

SETPOINTS

SETPOINT
 DOOR SETP
 UNOCC SETP
 VENT MIN SET
 COOLING FLOW
 TEMP SETP
 UNOCC TEMP
 MIN SUP DAMP
 MAX UP DAMP
 MIN EXH DAMP
 MAX EXH DAMP

ALARM

LOW ALARM
 HIGH ALARM
 DOOR LOW ALM
 DOOR HI ALM
 MIN SUP ALM
 ALARM RESET
 AUDIBLE ALM
 ALARM DELAY
 DOOR DELAY
 MUTE TIMEOUT

CONFIGURE

UNITS
 NET ADDRESS**
 LON**
 MAC ADDRESS**
 ACCESS CODES

CALIBRATION

SENSOR SPAN
 ELEVATION
 TEMP CAL

CONTROL

SPEED
 SENSITIVITY
 SUP CONT DIR
 EXH CONT DIR
 KC VALUE
 TI VALUE
 REHEAT SIG
 REHEAT DIR
 TEMP DB
 TEMP TR
 TEMP Ti

DIAGNOSTICS *

CONTROL SUP
 CONTROL EXH
 CONTROL TEMP
 SENSOR INPUT
 SENSOR STAT
 DOOR SWITCH
 UNOCC SWITCH
 SUP1 FLOW IN
 SUP2 FLOW IN***
 TEMP INPUT
 ALARM RELAY

SUPPLY FLOW

SP1 DCT AREA
 SP2 DCT AREA***
 SP1 FLO ZERO
 SP2 FLO ZERO***
 FLO STA TYPE
 TOP VELOCITY
 SP LOW SETP
 SP HIGH SETP
 SP1 LOW CAL
 SP1 HIGH CAL
 SP2 LOW CAL ***
 SP2 HIGH CAL ***
 RESET CAL

* Menu item description located in [Troubleshooting](#) section.

** LON Menu Item will only appear as a menu option for a Model 8636 Room Pressure Controller that includes an optional LonWorks® board. MAC ADDRESS Menu Item will only appear as a menu option for a Model 8636-BAC Room Pressure Controller which includes a BACnet® MSTP board. The Menu Item NET ADDRESS will be deleted as a menu option on the Model 8636 Room Pressure Controllers that include the optional LonWorks® board or BACnet® MSTP board.

*** These menu items do not appear as options when the controller includes the LonWorks® or BACnet® MSTP communication options.

Figure 5: Menu Items - Model 8636/8636-BAC Controller

®LonWorks® is a registered trademark of Echelon® Corporation.

SETPOINTS MENU				
MENU ITEM	SOFTWARE NAME	ITEM DESCRIPTION	ITEM RANGE	DEFAULT VALUE
PRESSURE SETPOINT	SETPOINT	<p>The SETPOINT item sets the pressure control setpoint. The SUREFLOW™ controller will maintain the room pressure, negative or positive, under normal operating conditions.</p> <p>This item is enabled when the SWITCH INPUT contact closure, pins 11 and 12, is open, or the RS 485 communications sends a command.</p>	0 to -0.19500" H ₂ O or 0 to +0.19500" H ₂ O	-0.00100" H₂O
DOOR MODE OR ALTERNATE PRESSURE SETPOINT	DOOR SETP	<p>The DOOR SETP item sets an alternate control setpoint. The SUREFLOW™ controller will maintain the room pressure at the alternate setpoint when this item is enabled.</p> <p>This item is enabled when the SWITCH INPUT contact closure, pins 11 and 12, is closed, or the RS 485 communications sends a command.</p> <p>NOTE: The DOOR SETP also enables the DOOR DELAY, and disables the ALARM DELAY.</p>	0 to -0.19500" H ₂ O or 0 to +0.19500" H ₂ O	0
UNOCCUPIED SUPPLY FLOW SETPOINT	UNOCC SETP	<p>The UNOCC SETP item sets the unoccupied mode minimum supply flow setpoint (CFM). This item provides supply air flow adequate to meet the unoccupied ventilation requirement, by preventing the supply flow from going below a preset minimum CFM. This item is enabled when the UNOCC IN contact closure, pins 19 and 20, is closed, or the RS 485 communications sends a command.</p> <p>The controller will not allow the supply air damper to be closed further than the UNOCC SETP setpoint. If room pressure is not maintained at minimum ventilation flow, the general exhaust damper modulates open until pressure setpoint is reached.</p> <p>NOTE: A TSI flow station is required to make the flow measurement and enable this function. The flow station and control damper must be mounted in the supply duct for this item to function properly.</p>	<p>0 to 30,000 CFM (0 to 14100 L/s)</p> <p>Linear based flow stations 0 to TOP VELOCITY times the duct area in square feet (ft²): square meters (m²).</p>	0

SETPOINTS MENU <i>(continued)</i>				
MENU ITEM	SOFTWARE NAME	ITEM DESCRIPTION	ITEM RANGE	DEFAULT VALUE
VENTILATION SUPPLY FLOW SETPOINT	VENT MIN SET	<p>The VENT MIN SET item sets the ventilation supply flow setpoint (CFM). This item provides supply air flow adequate to meet the ventilation requirement, by preventing the supply flow from going below a preset minimum CFM.</p> <p>The controller will not allow the supply air damper to be closed further than the VENT MIN SET setpoint. If room pressure is not maintained, at minimum supply flow, the general exhaust damper modulates open until pressure setpoint is reached.</p> <p>NOTE: A TSI flow station is required to make the flow measurement and enable this function. The flow station and control damper must be mounted in the supply duct for this item to function properly.</p>	<p>0 to 30,000 CFM (0 to 14100 L/s)</p> <p>Linear based flow stations 0 to TOP VELOCITY times the duct area in square feet (ft²): square meters (m²).</p>	0
SPACE COOLING SUPPLY FLOW SETPOINT	COOLING FLOW	<p>The COOLING FLOW item sets the space cooling supply flow setpoint (CFM). This item defines a supply air flow intended to meet the space's cooling requirements by allowing the supply flow to increase, gradually, to the COOLING FLOW setpoint, from a minimum ventilation rate, when the space temperature is too warm.</p> <p>If room pressure is not maintained, the supply flow gradually increases, which occurs in response to a warm space, the general exhaust damper modulates open until the space pressure setpoint is reached.</p> <p>WARNING: Care must be taken when programming the COOLING FLOW set point to ensure that the COOLING FLOW air flow does not exceed the spaces exhaust air flow capabilities and therefore the controller's ability to maintain the space pressure set point (SETPOINT).</p> <p>NOTE: A TSI flow station is required to make the flow measurement and enable this function. The flow station and control damper must be mounted in the supply duct for this item to function properly.</p>	<p>0 to 30,000 CFM (0 to 14100 L/s)</p> <p>Linear based flow stations 0 to TOP VELOCITY times the duct area in square feet (ft²): square meters (m²).</p>	0

SETPOINTS MENU <i>(continued)</i>				
MENU ITEM	SOFTWARE NAME	ITEM DESCRIPTION	ITEM RANGE	DEFAULT VALUE
TEMPERATURE SETPOINT	TEMP SETP	The TEMP SETP item sets the temperature control setpoint. The SUREFLOW™ controller will maintain the temperature setpoint under normal operating conditions.	50°F to 85°F	68°F
UNOCCUPIED TEMPERATURE SETPOINT	UNOCC TEMP	The UNOCC TEMP item sets the unoccupied mode temperature control setpoint. The SUREFLOW™ controller will maintain the temperature setpoint under normal operating conditions.	50°F to 85°F	68°F
MINIMUM SUPPLY DAMPER POSITION	MIN SUP DAMP	The MIN SUP DAMP menu item sets the supply damper minimum opening. The damper will not close more than this setpoint.	0% OPEN to 100% OPEN	0% OPEN
MAXIMUM SUPPLY DAMPER POSITION	MAX SUP DAMP	The MAX SUP DAMP menu item sets the supply damper maximum opening. The damper will not open more than this setpoint.	0% OPEN to 100% OPEN	100% OPEN
MINIMUM EXHAUST DAMPER POSITION	MIN EXH DAMP	The MIN EXH DAMP menu item sets the exhaust damper minimum opening. The damper will not close more than this setpoint.	0% OPEN to 100% OPEN	0% OPEN
MAXIMUM EXHAUST DAMPER POSITION	MAX EXH DAMP	The MAX EXH DAMP menu item sets the exhaust damper maximum opening. The damper will not open more than this setpoint.	0% OPEN to 100% OPEN	100% OPEN
	END OF MENU	The END OF MENU item informs you that the end of a menu has been reached. You can either scroll back up the menu to make changes, or press the SELECT or MENU key to exit out of the menu.		

ALARM MENU				
MENU ITEM	SOFTWARE NAME	ITEM DESCRIPTION	ITEM RANGE	DEFAULT VALUE
LOW PRESSURE ALARM	LOW ALARM	<p>The LOW ALARM item sets the low pressure alarm setpoint. A low alarm condition is defined as when of the room pressure falls below or goes in the opposite direction of the LOW ALARM setpoint.</p> <p>This item is enabled when the SWITCH INPUT contact closure, pins 11 and 12, is open, or the RS 485 communications sends a command.</p>	OFF, 0 to -0.19500" H ₂ O 0 to +0.19500" H ₂ O	OFF
HIGH PRESSURE ALARM	HIGH ALARM	<p>The HIGH ALARM item sets the high pressure alarm setpoint. A high alarm condition is defined as when of the room pressure rises above the HIGH ALARM setpoint.</p> <p>This item is enabled when the SWITCH INPUT contact closure, pins 11 and 12, is open, or the RS 485 communications sends a command.</p>	OFF, 0 to -0.19500" H ₂ O 0 to +0.19500" H ₂ O	OFF
DOOR OR SECOND LOW ALARM	DOOR LOW ALM	<p>The DOOR LOW ALM item sets a remote or second low pressure alarm setpoint. A remote low alarm condition is defined as when the room pressure falls below or goes in the opposite direction of the DOOR LOW ALM setpoint.</p> <p>This item is enabled when the SWITCH INPUT contact closure, pins 11 and 12, is closed, or the RS 485 communications sends a command.</p>	OFF, 0 to -0.19500" H ₂ O 0 to +0.19500" H ₂ O	OFF
DOOR OR SECOND HIGH ALARM	DOOR HI ALM	<p>The DOOR HI ALM item sets a remote or second high-pressure alarm setpoint. A high alarm condition is defined as when the room pressure rises above the DOOR HI ALM setpoint.</p> <p>This item is enabled when the SWITCH INPUT contact closure, pins 11 and 12, is closed, or the RS 485 communications sends a command.</p>	OFF, 0 to -0.19500" H ₂ O 0 to +0.19500" H ₂ O	OFF

ALARM MENU <i>(continued)</i>				
MENU ITEM	SOFTWARE NAME	ITEM DESCRIPTION	ITEM RANGE	DEFAULT VALUE
MINIMUM SUPPLY FLOW ALARM	MIN SUP ALM	<p>The MIN SUP ALM item sets the supply duct's flow alarm setpoint. A minimum flow alarm is defined as when the supply duct flow is less than the MIN SUP ALM setpoint.</p> <p>The MIN SUP ALM item must be less than the VENT MIN SET item.</p> <p>NOTE: Supply air duct size SUP DCT AREA (configure menu) must be entered before MIN SUP ALM can be accessed.</p>	0 to 30,000 CFM (0 to 14100 L/s)	OFF
ALARM RESET	ALARM RESET	<p>The ALARM RESET item selects how the alarms terminate after the unit returns to control setpoint (pressure or flow). UNLATCHED (alarm follow) automatically resets the alarms when the unit reaches control setpoint. LATCHED requires the staff to press the RESET key after the unit returns to control setpoint. The ALARM RESET affects the audible alarm, visual alarm, and relay output, which means all are latched or unlatched.</p>	LATCHED OR UNLATCHED	UNLATCHED
AUDIBLE ALARM	AUDIBLE ALM	<p>The AUDIBLE ALM item selects whether the audible alarm is turned ON or OFF. Selecting ON requires the staff to press the MUTE key to silence the audible alarm. Selecting OFF permanently mutes all audible alarms, except when the EMERGENCY key is pressed.</p>	ON or OFF	ON
ALARM DELAY	ALARM DELAY	<p>The ALARM DELAY determines the length of time the alarm is delayed after an alarm condition has been detected. This delay affects the visual alarm, audible alarm, and relay outputs. An ALARM DELAY prevents nuisance alarms from people entering and leaving the laboratory.</p> <p>The ALARM DELAY is enabled when the SWITCH INPUT contact closure, pins 11 and 12, is open, or the RS 485 communications sends a command.</p>	20 to 600 SECONDS	20 SECONDS

ALARM MENU <i>(continued)</i>				
MENU ITEM	SOFTWARE NAME	ITEM DESCRIPTION	ITEM RANGE	DEFAULT VALUE
DOOR DELAY	DOOR DELAY	<p>The DOOR DELAY item is an alarm delay used when the door will be open for an extended period of time. The DOOR DELAY is usually set for a longer period of time than the ALARM DELAY. This delay affects the visual alarm, audible alarm, and relay outputs. The DOOR DELAY prevents nuisance alarms from people leaving the doors open to move equipment into or out of the laboratory, or when a large group will be entering or leaving the laboratory.</p> <p>The DOOR DELAY is enabled when the SWITCH INPUT contact closure, pins 11 and 12, is closed, or the RS 485 communications sends a command.</p> <p>NOTE: When the switch input is closed, the remote setpoint and remote alarms are activated, and the standard setpoint alarms, and alarm delay are turned off. Set the REMOTE SETPOINT and remote alarms equal to the standard SETPOINT and alarms if the same pressure control is required.</p>	20 to 600 SECONDS	20 SECONDS
MUTE TIMEOUT	MUTE TIMEOUT	<p>The MUTE TIMEOUT determines the length of time the audible alarm is silenced after the MUTE key is pressed. This delay temporarily mutes the audible alarm.</p> <p>NOTE: If the DIM is in alarm when MUTE TIMEOUT expires, the audible alarm turns on. When the pressure returns to the safe range, the MUTE TIMEOUT is canceled. If the room goes back into an alarm condition, the MUTE key must be pressed again to mute the audible alarm.</p>	5 to 30 MINUTES	5 MINUTES
	END OF MENU	<p>The END OF MENU item informs you that the end of a menu has been reached. You can either scroll back up the menu to make changes, or press the SELECT or MENU key to exit out of the menu.</p>		

ALARM CONSTRAINTS

There are a number of constraints built into the software that prevent users from programming conflicting alarm information. These are as follows:

1. Remote alarms. The remote alarms are only active when the switch input (pins 11 and 12) is closed, which activates the remote or second setpoint. When the remote or second setpoint are active, the standard alarms are turned off.
2. The SUREFLOW™ controller is programmed not to allow the pressure alarms to be programmed within 20 ft/min (0.00028" H₂O at 0.001" H₂O) of the control setpoint.

Example: The control SETPOINT is set at -0.001" H₂O. The LOW ALARM setpoint cannot be set higher than -0.00072" H₂O. Conversely if your control SETPOINT is set at -0.001" H₂O, the HIGH ALARM setpoint cannot be set lower than -0.00128" H₂O.
3. The minimum *flow* alarms must be programmed to be at least 50 CFM *less* than the minimum flow setpoint.
4. The alarms, both standard and remote, can be programmed for positive or negative pressure. However, both the low and high alarm must be set either positive or negative. The DIM does not allow one positive alarm and one negative alarm.
5. Alarms do not terminate until the pressure or flow exceeds the alarm setpoint. The alarm setpoint must be slightly exceeded before alarm will terminate.
6. The ALARM RESET item selects how the alarms will terminate when controller returns to the safe range. The pressure and flow alarms all terminate the same; they are either latched or unlatched. If unlatched is selected the alarms automatically turn off when the value slightly exceeds the control setpoint. If latched is selected the alarms will not terminate until the controller returns to setpoint *and* the **RESET** key is pressed.
7. There is a programmable ALARM DELAY (and optional DOOR DELAY) that determines how long to delay before activating the alarms. This delay affects all pressure and flow alarms.
8. The MUTE TIMEOUT item temporarily turns the audible alarm off for all pressure and flow alarms.

9. The display can only show one alarm message. Therefore, the controller has an alarm priority system, with the highest priority alarm being displayed. If multiple alarms exist, the lower priority alarms will not display until after the highest priority alarm has been eliminated. The alarm priority is as follows:

Pressure sensor - low alarm
 Pressure sensor - high alarm
 Flow station - minimum supply flow
 Data error

10. The low and high alarms are absolute values. The chart below shows how the values must be programmed in order to operate correctly.

-0.2 inches H₂O (maximum negative)		0 Zero		+0.2 inches H₂O (maximum positive)		
High Negative Alarm	Negative Setpoint	Low Negative Alarm		Low Positive Alarm	Positive Setpoint	High Positive Alarm

The value of each setpoint or alarm is unimportant (except for small dead band) in graph above. It is important to understand that the negative (positive) low alarm must be between zero (0) pressure and the negative (positive) setpoint, and that the high alarm is a greater negative (positive) value than setpoint.

CONFIGURE MENU				
MENU ITEM	SOFTWARE NAME	ITEM DESCRIPTION	ITEM RANGE	DEFAULT VALUE
UNITS	UNITS	The UNITS item selects the unit of measure that the controller displays all values (except calibration span). These units display for all menu items setpoints, alarms, flows, etc.	FT/MIN, m/s, " H ₂ O Pa	"H ₂ O
NETWORK ADDRESS	NET ADDRESS	<p>The NET ADDRESS item is used to select the Modbus network address of the individual room pressure device. Each unit on the network must have its own unique address. The values range from 1-247. If RS-485 communications are being used, then a unique NET ADDRESS must be entered into the unit.</p> <p>There is no priority between the RS-485 and keypad. The most recent signal by either RS-485 or keypad will initiate a change.</p> <p>RS-485 communications allows you access to all menu items except calibration items. The RS-485 network can initiate a change at any time.</p>	1 to 247	1
LON**	LON	<p>When the SERVICE PIN option is selected, the Model 8636 sends a broadcast message containing its Neuron ID and program ID. This is required to install the Model 8636 on the LonWorks[®] network, or to reinstall the Model 8636 after using the GO UNCONFIGURED command.</p> <p>Selecting the GO UNCONFIGURED option resets the Model 8636's authentication key. This is required in the event a foreign network tool inadvertently acquires a Model 8636 and installs it with network management authentication. The Model 8636's owner will then be unable to reclaim the Model 8636 over the network.</p>	SERVICE PIN or GO UNCONFIGURED	

**The LON Menu Item will replace the Network Address Menu Item on SUREFLOW™ controllers provided with the LonWorks[®] board.

CONFIGURE MENU <i>(continued)</i>				
MENU ITEM	SOFTWARE NAME	ITEM DESCRIPTION	ITEM RANGE	DEFAULT VALUE
MAC Address**	MAC ADDRESS	The MAC ADDRESS assigns the device an address on the MS/TP BACnet® network. This address must be unique for each device on the BACnet® network	1 to 127	1
ACCESS CODES	ACCESS CODES	The ACCESS CODE item selects whether an access code (pass code) is required to enter any menu. The ACCESS CODE item prevents unauthorized access to all menus. If the ACCESS CODE is ON a code is required before the menu can be entered. Conversely if the ACCESS CODE is OFF no code is required to enter the menu.	ON or OFF	OFF
	END OF MENU	The END OF MENU item informs you that the end of a menu has been reached. You can either scroll back up the menu to make changes, or press the SELECT or MENU key to exit out of the menu.		

**The MAC ADDRESS Menu Item will replace the Network Address Menu Item on SUREFLOW™ controllers provided with the BACnet® MSTP board.

CALIBRATION MENU				
MENU ITEM	SOFTWARE NAME	ITEM DESCRIPTION	ITEM RANGE	DEFAULT VALUE
SENSOR SPAN	SENSOR SPAN	The SENSOR SPAN item is used to match or calibrate the SUREFLOW™ velocity sensors to the average room pressure velocity as measured by a portable air velocity meter. A sensor zero should be established prior to adjusting the sensor span (see Calibration section following menu item listing).	NONE	Unit is factory calibrated. No initial adjustment should be necessary.
ELEVATION	ELEVATION	The ELEVATION item is used to enter the elevation of the building above sea level. This item has a range of 0-10,000 feet in 1,000 foot increments. The pressure value needs to be corrected due to changes in air density at different elevations.	0 to 10,000 feet above sea level	0
TEMP CALIBRATION	TEMP CAL	The TEMP CAL item is used to match or calibrate the SUREFLOW™ temperature sensor to the actual space temperature as measured by a portable meter.	NONE	
	END OF MENU	The END OF MENU item informs you that the end of a menu has been reached. You can either scroll back up the menu to make changes, or press the SELECT or MENU key to exit out of the menu.		

CONTROL MENU				
MENU ITEM	SOFTWARE NAME	ITEM DESCRIPTION	ITEM RANGE	DEFAULT VALUE
SPEED	SPEED	<p>The SPEED item is used to select the control output speed. When this item is selected, a bar graph is shown on the display. There are 10 bars, each one representing 10% of speed. Starting from the right side (+ sign), 10 bars displayed indicates maximum speed. This is the fastest the controller will operate. 1 bar is the slowest the control output will move. The more bars shown, the faster the control output.</p>	1 to 10 bars	5 bars
SENSITIVITY	SENSITIVITY	<p>The SENSITIVITY item is used to select the integral dead band. The integral dead band determines when the controller uses integral control (slow control), and when the controller enters PID control (fast control). When this item is selected, a bar graph will be shown on the display. There are 10 bars each representing ± 10 ft/min</p> <p>Starting from the right side (+ sign), 10 bars displayed indicates no dead band so the controller will always be in PID control mode. The less bars displayed, the larger the integral dead band. For example, with 8 bars displayed and an operating setpoint of 100 ft/min, the integral dead band is between 80 and 120 ft/min. When the measured room pressure velocity is within this range, integral or slow control is used. However, when the room pressure velocity falls below 80 ft/min or rises above 120 ft/min, PID control is enabled until the unit returns within the dead band.</p> <p>The SENSITIVITY item has a unique feature that when zero bars are displayed, the unit never goes into PID control. The control output is a slow control signal.</p> <p>WARNING: When SENSITIVITY is set for 10 bars, the system is always in PID control, which will probably cause an unstable system. It is recommended that the SENSITIVITY be set at 9 bars or less.</p>	0 to 10 bars	5 bars

CONTROL MENU <i>(continued)</i>				
MENU ITEM	SOFTWARE NAME	ITEM DESCRIPTION	ITEM RANGE	DEFAULT VALUE
SUPPLY CONTROL DIRECTION	SUP CONT DIR	The SUP CONT SIG item determines the supply control signal's output direction. As an example; if the control system closes the supply damper instead of opening the damper, this option will reverse the control signal to now open the damper.	Direct or Reverse	Direct
EXHAUST CONTROL DIRECTION	EXH CONT DIR	The EXH CONT SIG item determines the exhaust control signal's output direction. As an example; if the control system closes the exhaust damper instead of opening the damper, this option will reverse the control signal to now open the damper.	Direct or Reverse	Direct

CONTROL MENU <i>(continued)</i>					
MENU ITEM	SOFTWARE NAME	ITEM DESCRIPTION		ITEM RANGE	DEFAULT VALUE
Kc VALUE Ti VALUE	Kc VALUE Ti VALUE	<p>WARNING: The Kc VALUE and Ti VALUE items provides you with the ability to manually change the PID control loop variables. DO NOT CHANGE THESE VALUES UNLESS YOU HAVE A THOROUGH UNDERSTANDING OF PID CONTROL LOOPS. CONTACT TSI FOR ASSISTANCE PRIOR TO CHANGING ANY VALUES. Contact TSI for assistance in determining your control problem and for instructions on how to change a value. Incorrectly changing a value will result in poor or nonexistent control.</p> <p>Suggestion: Before changing Kc or Ti change the speed or adjust the sensitivity to try to eliminate the problem.</p> <p>The Kc VALUE item is used to read and change the gain control coefficient. When this item is entered, a value for Kc is indicated on the display. If the SUREFLOW™ controller is not controlling correctly, the Kc gain control coefficient may need adjusting. Decreasing Kc will slow the control system down, which will increase stability. Increasing Kc will increase the control system which may cause system instability.</p> <p>The Ti VALUE item is used to read and change the integral control coefficient. When this item is entered, a value for Ti is indicated on the display. If the SUREFLOW™ controller is not controlling correctly, the unit may have an inappropriate integral control coefficient. Increasing Ti will slow the control system which will increase stability. Decreasing Ti will increase the control system which may cause system instability.</p> <p>WARNING: Setting Kc or Ti to zero turns the control output signal off causing the unit to act like a monitor.</p>		Kc = 0 to 1000 Ti = 0 to 1000	Kc = 100 Ti = 200

CONTROL MENU <i>(continued)</i>				
MENU ITEM	SOFTWARE NAME	ITEM DESCRIPTION	ITEM RANGE	DEFAULT VALUE
REHEAT CONTROL SIGNAL	REHEAT SIG	The REHEAT SIG item switches the temperature control output from 0 to 10 VDC to 4 to 20 mA.	4 to 20 mA or 0 to 10 VDC	0 to 10 VDC
REHEAT CONTROL DIRECTION	REHEAT DIR	The REHEAT DIR item determines the temperature control signal's output direction. As an example; if the control system closes the reheat valve instead of opening the valve, this option will reverse the control signal to now open the valve.	Direct or Reverse	Direct
TEMPERATURE SETPOINT DEAD BAND	TEMP DB	The TEMP DB item determines the controller's temperature control deadband, which is defined as the temperature range above <u>and</u> below the temperature set point (TEMP SETP), where the controller will not take corrective action.	0.0 °F to ±1.0 °F	±0.1 °F

If TEMP DB is set to 1.0°F, and the TEMP SETP is set to 70.0°F, the controller will not take corrective action unless the space temperature is below 69.0°F or above 71.0°F.

CONTROL MENU <i>(continued)</i>				
MENU ITEM	SOFTWARE NAME	ITEM DESCRIPTION	ITEM RANGE	DEFAULT VALUE
TEMPERATURE SETPOINT THROTTLING RANGE	TEMP TR	The TEMP TR item determines the controller's temperature control throttling range, which is defined as the temperature range for the controller to fully open and fully close the reheat valve.	$\pm 2.0^{\circ}\text{F}$ to $\pm 20.0^{\circ}\text{F}$	$\pm 3.0^{\circ}\text{F}$

Temperature (F)	% Open
65	100
66	100
67	100
70	50
73	0
74	0
75	0

If TEMP TR is set to $\pm 3.0^{\circ}\text{F}$, and the TEMP SETP is set to 70.0°F , the reheat valve will be fully open when the space temperature is 67°F . Similarly, the reheat valve will be fully closed when the space temperature is 73.0°F .

CONTROL MENU <i>(continued)</i>				
MENU ITEM	SOFTWARE NAME	ITEM DESCRIPTION	ITEM RANGE	DEFAULT VALUE
TEMPERATURE SETPONT INTEGRAL VALUE	TEMP Ti VAL	<p>WARNING: The TEMP Ti VAL item provides you with the ability to manually change the temperature control PI integral control loop variable. DO NOT CHANGE THIS VALUE UNLESS YOU HAVE A THOROUGH UNDERSTANDING OF PI CONTROL LOOPS. CONTACT TSI FOR ASSISTANCE PRIOR TO CHANGING ANY VALUES.</p> <p>Contact TSI for assistance in determining your control problem and for instructions on how to change a value. Incorrectly changing a value will result in poor or nonexistent control.</p> <p>Suggestion: Before changing TEMP Ti VAL adjust the TEMP DB or adjust the TEMP TR to try to eliminate the problem.</p> <p>The TEMP Ti VAL item is used to read and change the integral control coefficient. When this item is entered, a value for TEMP Ti VAL is indicated on the display. If the SUREFLOW™ controller is not controlling correctly, the unit may have an inappropriate integral control coefficient. Increasing TEMP Ti VAL will slow the control system which will increase stability. Decreasing TEMP Ti VAL will speed up the control system which may cause system instability.</p>	1 to 10000 sec	2400 sec
	END OF MENU	The END OF MENU item informs you that the end of a menu has been reached. You can either scroll back up the menu to make changes, or press the SELECT or MENU key to exit out of the menu.		

SUPPLY FLOW MENU				
MENU ITEM	SOFTWARE NAME	ITEM DESCRIPTION	ITEM RANGE	DEFAULT VALUE
SUPPLY FLOW DUCT AREA	SP1 DCT AREA SP2 DCT AREA*	<p>The SP# DCT AREA items are used to input the supply duct size. The duct size is needed to compute the flow into the room. This item requires a flow station to be mounted in the supply duct.</p> <p>When a duct area is programmed, the display will automatically scroll the actual supply flow as part of the display sequence. If a zero value is entered, the supply flow value will not scroll on the display.</p> <p>If the DIM displays English units, area must be entered in square feet. If metric units are displayed, area must be entered in square meters.</p>	0 to 10 square feet (0 to 0.9500 square meters)	0
SUPPLY FLOW ZERO	SP1 FLO ZERO SP2 FLO ZERO*	<p>The SP# FLO ZERO items are used to establish the flow station zero flow point. A zero or no flow point needs to be established prior to using the flow measurement output (see Calibration section following menu item listing).</p> <p>All <u>pressure</u>-based flow stations need to have a SP# FLO ZERO established on initial set up. <u>Linear</u> flow stations with a 1-5 VDC output also need to have a SP# FLO ZERO established. Linear flow stations with a 0-5 VDC output do not need a SP# FLO ZERO.</p>	NONE	
FLOW STATION TYPE	FLO STA TYPE	The FLO STA TYPE item is used to select the flow station input signal. PRESSURE is selected when TSI flow stations with pressure transducers are installed. LINEAR is selected when a linear output flow station, typically thermal anemometer based, is installed.	PRESSURE LINEAR	PRESSURE

*These menu items do not appear on Model 8636-BAC or Model 8636-LN.

SUPPLY FLOW MENU <i>(continued)</i>				
MENU ITEM	SOFTWARE NAME	ITEM DESCRIPTION	ITEM RANGE	DEFAULT VALUE
MAXIMUM FLOW STATION VELOCITY	TOP VELOCITY	The TOP VELOCITY item is used to input the maximum velocity of a <u>linear</u> flow station output. A TOP VELOCITY must be input for the linear flow station to operate. NOTE: This item is disabled if a pressure-based flow station is installed.	0 to 5,000 FT/MIN (0 to 25.4 m/s)	0
LOW CALIBRATION DAMPER POSITION	SP LOW SETP	The SP LOW SETP menu item sets the supply damper position for supply low flow calibration.	0 to 255	
HIGH CALIBRATION DAMPER POSITION	SP HIGH SETP	The SP HIGH SETP menu item sets the supply damper position for supply high flow calibration.	0 to 255	
SUPPLY LOW FLOW CALIBRATION	SP1 LOW CAL	The SP# LOW CAL menu items are used to obtain a correct flow measurement output (see Calibration section).	0 to 30,000 CFM (0 to 14100 L/S)	
	SP2 LOW CAL*	All flow stations need to have a SP# LOW CAL established on initial set up.		
SUPPLY HIGH FLOW CALIBRATION	SP1 HIGH CAL	The SP# HIGH CAL menu items are used to obtain a correct flow measurement output (see Calibration section).	0 to 30,000 CFM (0 to 14100 L/S)	
	SP2 HIGH CAL*	All flow stations need to have a SP# HIGH CAL established on initial set up.		
RESET CALIBRATION	RESET CAL	The RESET CAL menu item is used to clear the field calibration of both supply flow stations.		
	END OF MENU	The END OF MENU item informs the user that the end of a menu has been reached. The user can either scroll back up the menu to make changes, or press the SELECT or MENU key to exit out of the menu.		

*These menu items do not appear on Mode 8636-BAC or Model 8636 8636-LN.

Setup / Checkout

The Model 8636 is easy to program and setup. This section covers the theory of operation, required software programming, a programming example, and how to verify (checkout) that the components are functioning correctly. The Model 8636 uses a unique control sequence that combines flow and pressure differential measurements to maintain air balance and laboratory pressure, while interfacing with a thermostat to maintain laboratory temperature. The overall Model 8636 control sequence seems quite complicated initially, but the [Theory of Operation](#) section breaks the sequence down into sub-sequences which simplifies the total system.

Theory of Operation

The Model 8636 control system requires the following measurement inputs to function correctly:

- Supply air flow measured with a flow station.
- Temperature measured with a temperature sensor, a 1000 Ω Platinum RTD (if temperature is incorporated into sequence).
- Pressure differential with a TSI pressure sensor.

Laboratory air balance

Laboratory air balance is maintained by measuring the pressure difference between the lab and the reference space and modulating the general exhaust to maintain the required pressure differential. The supply air flow is measured to allow the Model 8636 to adequately ventilate the lab space; provide a minimum ACPH. Additionally, supply flow measurement is required to allow the Model 8636 to increase supply air flow to cool the lab (if temperature control is incorporated into the control sequence). The general exhaust modulates to maintain the pressure differential.

Pressure Control Sequence:

The Model 8636 receives the pressure differential signal from the pressure sensor. If pressure is at set point, the control algorithm maintains supply and general exhaust control outputs. If pressure is not at set point, the exhaust and/or supply control output is changed until pressure is maintained, or the minimum or maximum damper positions are reached.

If the pressure is below set point (too negative or not positive enough):

The controller will first decrease the general exhaust until one of the following events occur:

- Pressure set point is reached. The Model 8636 maintains the new control outputs.
- The general exhaust damper position reaches the MIN EXH DAMP set point position. An optional alarm will trigger to inform the user pressure differential is not being maintained.
- If the general exhaust is fully closed, as determined by either the MIN EXH DAMP set point or the physical position of the damper, the supply will be increased until the room pressure set point is reached or until the supply flow reaches MAX SUP SETP flow set point position.

If the controller has fully closed the general exhaust and is modulating the supply flow to control space pressure and there is a rapid reduction in pressure, for instance, a fume hood is closed, the controller will quickly react by closing the supply. The supply flow will not be allowed to drop below the VENT MIN SET. Once the supply flow reaches the VENT MIN SET flow rate, the controller will then immediately control the general exhaust to maintain pressure.

If the pressure is above set point (too positive or not negative enough):

The controller will first increase the general exhaust until one of the following events occur:

- Pressure set point is reached. The Model 8636 maintains the new control outputs.
- The general exhaust damper position reaches the MAX EXH DAMP set point position. An optional alarm will trigger to inform the user pressure differential is not being maintained.

The Model 8636 continuously monitors and displays pressure differential between the laboratory and corridor (reference space). When the pressure differential is adequate, a green light indicates a safe pressure differential is being maintained. Room pressure alarm set points, configured into the controller, activate a red light and audible alarm when the room pressure becomes insufficient or too great. In addition to a local indication of room pressure, alarm contacts and RS 485 communications may be used to provide extensive information to a building management system.

Temperature Control Sequence:

The 8636 receives a temperature input from a temperature sensor (1000 Ω Platinum RTD). The Model 8636 controller maintains temperature control by:

- (1) Controlling supply and general exhaust for ventilation and cooling
- (2) Controlling the reheat coil for heating

The Model 8636 has three supply flow minimum set points. The ventilation set point (VENT MIN SET) is the minimum flow volume required to meet ventilation needs of the laboratory (ACPH). The temperature supply set point (COOLING FLOW) is the theoretical minimum flow required to meet cooling flow needs of the laboratory. The unoccupied set point (UNOCC SETP) is the minimum flow required when the lab is not occupied. All of these set points are configurable. If the Model 8636 is in the Unoccupied Mode, the controller will control the supply air flow to the UNOCCUPY SET ventilation rate, the supply flow will not be modulated for space cooling; space temperature control will be maintained by modulating the reheat coil.

The Model 8636 continuously compares the temperature set point to the actual space temperature. If set point is being maintained, no changes are made. If set point is not being maintained, and the space temperature is rising, the controller will first modulate the reheat valve closed. Once the reheat valve is fully closed the controller will begin a 3 minute time period. If, after the 3 minute time period the reheat valve is still fully closed, the Model 8636 will then gradually begin increasing the supply volume by 1 CFM/second up to the COOLING FLOW set point.

The controller, when controlling supply flow for cooling, will not increase the supply flow above the COOLING FLOW ventilation rate. If the space temperature decreases below the set point, the controller will first reduce the supply volume. Once the supply volume reaches its minimum (VENT MIN SET), the controller will then start a 3 minute time period. If, after 3 minutes the supply flow is still at the VENT MIN SET flow rate, the controller will begin modulating the reheat coil open to meet the heating demand.

If the general exhaust is in the closed position and fume hood loads require additional replacement air, the Model 8636 will override ventilation or temperature set points to modulate supply for pressurization control. Temperature will then be controlled by the reheat valve in this sequence.

The control output items in the DIAGNOSTICS menu will show a percentage value. If control direction for a given output is set to DIRECT, the diagnostic value will be percent OPEN. If control direction for a given output is set to REVERSE, the diagnostic value will be percent CLOSED.

NOTE: The greatest flow requirement dominates the supply flow. If hood replacement air exceeds the ventilation or temperature flow minimums, the replacement air requirement is maintained (minimums are ignored).

In summary, understanding the Model 8636 control algorithm is the key to getting the system functioning correctly.

Required Software Programming

The following menu items must be programmed for the Model 8636 to function. See [Menu and Menu Items](#) section for information in individual menu items.

SUPPLY FLOW MENU	SETPOINT MENU
SP1 DCT AREA	SETPOINT
SP2 DCT AREA*	DOOR SETP
SP1 FLO ZERO	UNOCC SETP***
SP2 FLO ZERO*	VENT MIN SET
FLO STA TYPE	COOLING FLOW**
TOP VELOCITY	TEMP SETP**
SP LOW SETP	
SP HIGH SETP	
SP1 LOW CAL	
SP1 HIGH CAL	
SP2 LOW CAL*	
SP2 HIGH CAL*	

* Required only if the lab has two supply VAV flow requirements.

** Required only if the controller is to control space temperature.

*** Required only if the sequence of operations utilizes an Unoccupied Mode flow set point; i.e., has an Unoccupied Mode.

NOTE: If temperature control is being maintained by the Model 8636, the following menu items must also be programmed:

- **Temperature** - The temperature cooling and heating values: VENT MIN SET, COOLING FLOW, and TEMP SETP.

There are additional programmable software menu items to tailor the controller to your specific application or increase flexibility. These menu items are not required to be programmed for the Model 8638 to operate.

Programming Example:

The laboratory shown in Figure 6 is being initially setup. The required HVAC information is below the figure.




Figure 6: Laboratory Setup Example

Laboratory design:

Laboratory size	=	12' × 14' × 10'	(1,680 ft ³).
5 foot fume hood	=	250 CFM min*	1,000 CFM max*
Flow offset	=	100 - 500 CFM*	
Ventilation set point	=	280 CFM*	(ACPH = 10)
Supply Cooling Volume	=	400 CFM*	
Pressure differential	=	-0.001 " H ₂ O*	
Temperature setpoint	=	72°F	

* Value supplied by laboratory designer.

Room Pressure Control System:

- (1) Model 8636 Direct Pressure Control System mounted in the laboratory.
- (2) A through-the-wall pressure sensor mounted between the corridor (referenced space) and laboratory (controlled space).
- (3) Damper, pressure dependent VAV box or venturi valve with actuator assembly mounted in supply air duct(s).
- (4) Damper, pressure dependent VAV box or venturi valve with actuator assembly mounted in exhaust air duct.
- (5) Flow station mounted in supply air duct. (Required for non-venturi valve applications only).

Temperature Control System:

- (1) Temperature Sensor (1000Ω RTD) mounted in the laboratory.
- (2) Reheat coil mounted in supply air duct(s).

Fume Hood Control System:

- (1) Independent SUREFLOW™ VAV Face Velocity Control system.

Based on the preceding information, and knowing duct sizes, the following required menu items can be programmed:

MENU ITEM	ITEM VALUE	DESCRIPTION
SUP DCT AREA	1.0 ft ² (12" × 12")	Supply duct area
<i>Additional menu items to program for temperature and pressure control.</i>		
VENT MIN SET	280 CFM	10 air changes per hour
COOLING FLOW	400 CFM	Required flow to cool laboratory.
TEMP SETP	72°F	Laboratory temperature set point.
SETPOINT	-0.001 " H ₂ O	Pressure differential set point.

Sequence Of Operation

Beginning scenario:

Laboratory is maintaining pressure control; -0.001 " H₂O.

Temperature requirement is satisfied.

Fume hood sashes are down, total hood exhaust is 250 CFM.

Supply air is 280 CFM (maintain ventilation).

General exhaust flow is not measured.

The general exhaust flow is modulated to maintain the pressure differential.

The fume hood is opened so that the chemists can load experiments into the hood. The face velocity (100 ft/min) is maintained by the fume hood face velocity controllers by modulating the fume hood dampers. The total fume hood flow is now 1,000 CFM.

The general exhaust damper will first be modulated closed in order to maintain the pressure differential. Once the general exhaust damper is fully closed the supply air volume will then be increased to maintain the pressure differential. The supply air volume will nominally be increased to 900 CFM

The hood is shut after the experiments are loaded so the fume hood exhaust flow decreases to 250 CFM. .

The supply flow will first be reduced to its minimum flow (VENT MIN SET). Once the supply flow reaches its minimum, the general exhaust will be modulated to maintain pressure.

An oven is turned on and the laboratory is getting warm. The rise in space temperature is measured by the space temperature sensor. The controller will first close the reheat valve, and begin a 3-minute time period. If, after the 3-minute time period the space temperature is still to warm, the controller will gradually increase the supply flow to the COOLING FLOW set point. This increases the supply air to 400 CFM. The general exhaust air must also increase (damper opens) to maintain the pressure differential.

The control loop continuously keeps the room pressure, and temperature control satisfied.

Checkout

The controller should have the individual components checked prior to attempting control of the laboratory. The checkout procedure outlined below will confirm all hardware is performing correctly. The checkout procedure is not difficult and will catch any hardware problems. The steps are as follows:

Confirm wiring is correct.

The most common problem with installed hardware equipment is incorrect wiring. This problem usually exists on initial installation, or when modifications to the system take place. The wiring should be very closely checked to verify it *exactly* matches the wiring diagram. Polarity must be observed for system to operate correctly. The TSI provided cables are all color coded to ensure proper wiring. A wiring diagram is located in [Appendix B](#) of this manual. Wiring associated with non TSI components should be closely checked for correct installation.

Confirming physical installation is correct

All of the hardware components need to be installed properly. Review the installation instructions and verify components are installed properly at the correct location. This can be easily confirmed when checking the wiring.

Verifying individual components

Verifying all TSI components are operating correctly requires following a simple procedure. The fastest procedure involves first checking the DIM, and then confirming all component parts are functioning.

NOTE: These checks require power to the controller and all components.

CHECK - DIM

Press **TEST** key to verify Digital Interface Module (DIM) electronics are functioning correctly. At the end of the self test, the display will show **SELF TEST - PASSED** if DIM electronics are good. If unit displays **DATA ERROR** at the end of the test, the electronics may be corrupted. Check all software items to determine cause of **DATA ERROR**. Pressing **RESET** will clear the **DATA ERROR** from the controller.

If **SELF TEST - PASSED** was displayed proceed to check individual components. Enter **Diagnostics and Flow Check Menu** to check the following:

- Control output - supply (if controlling supply air).
- Control output - exhaust (if controlling exhaust air).
- Control output - reheat (if controlling reheat valve).
- Sensor input (if pressure sensor is installed).
- Sensor status (if pressure sensor installed).
- Temperature input.
- Supply flow station.

The menu items are explained in detail in the [Menu and Menu Items](#) section of the manual, so their function is not reviewed here. If the Model 8636 system passes each of the checks, the mechanical piece parts are all functioning correctly.

CHECK - Control output - supply

Enter **CONTROL SUP** menu item in diagnostics menu. A number between 0% OPEN and 100% OPEN will be displayed. Press the **▲/▼** keys until either 0% OPEN or 100% OPEN shows on the display. Note the position of the supply air control damper. If display reads 0% OPEN, press the **▲** key until 100% OPEN is shown on display. If display read 100% OPEN press **▼** key until 0% OPEN is shown on display. Note the position of the

supply air damper. The damper should have rotated either 45 or 90 degrees depending on actuator installed. If not, see the hardware section [Control system is not controlling](#).

CHECK - Control output - exhaust

Enter CONTROL EXH menu item in diagnostics menu. A number between 0% OPEN and 100% OPEN will be displayed. Press the ▲/▼ keys until either 0% OPEN or 100% OPEN shows on the display. Note the position of the general exhaust control damper. If display reads, 0% OPEN press the ▲ key until 100% OPEN is shown on display. If display read 100% OPEN press ▼ key until 0% OPEN is shown on display. Note the position of the general exhaust damper. The damper should have rotated either 45 or 90 degrees depending on actuator installed. If not, see the hardware section [Control system is not controlling](#).

CHECK - Control output - temperature

Enter CONTROL TEMP menu item in diagnostics menu. A number between 0% OPEN and 100% OPEN will be displayed. Press the ▲/▼ keys until either 0% OPEN or 100% OPEN shows on the display. Note the position of the reheat valve. If display reads 0% OPEN, press the ▲ key until 100% OPEN is shown on display. If display read 100% OPEN press ▼ key until 0% OPEN is shown on display. Note the position of the reheat valve. The damper should have moved through its full stroke. If not, see hardware section [Control system is not controlling](#). Reheat valves typically move slowly, so you may have to wait to see the full motion.

CHECK - Sensor input

Enter SENSOR INPUT menu item in diagnostics menu. A voltage between 0 and 10 volts DC will be displayed. It is not important what the exact voltage is to pass this test. Tape over the pressure sensor (slide pressure sensor door open) and voltage should read approximately 5 volts (zero pressure). Remove tape and blow on sensor. Displayed value should change. If voltage changes, the sensor is functioning correctly. If voltage doesn't change, proceed to [CHECK - Sensor status](#).

CHECK - Sensor status

Enter SENSOR STAT menu item in diagnostics menu. If NORMAL is displayed, the unit passes test. If an error message is displayed, go to diagnostics menu section of the manual, SENSOR STAT menu item for explanation of error message.

CHECK – Temperature sensor input

Enter TEMP INPUT menu item in diagnostics menu. When this item is entered, a temperature, via a 1000Ω platinum RTD, will be indicated on the display. The exact temperature displayed is relatively unimportant. It is more important that the temperature is changing which indicates the sensor is working correctly.

CHECK – Supply Flow:

The SUP1 FLOW IN and SUP2 FLOW IN items list all the flow stations that can be installed. Check each flow station menu item that has a flow station attached. Enter ____ FLOW IN menu item and the actual flow will be displayed. If the flow is correct, no changes need to be made. If flow is incorrect, adjust the corresponding ____ DCT AREA until actual flow matches flow station reading.

If unit passed all checks, the mechanical components are physically working.

Calibration

The calibration section explains how to calibrate the SUREFLOW™ pressure sensor, including setting the proper elevation, and how to zero a flow station.

NOTE: The SUREFLOW™ pressure sensor is factory calibrated and normally does not need to be adjusted. However, inaccurate readings may be detected if pressure sensor is not installed correctly, or problems with the sensor exists. First check that the sensor is installed correctly (usually only a problem on initial set up). Second, go into **DIAGNOSTICS** menu, **SENSOR STAT** item. If **NORMAL** is displayed, calibration can be adjusted. If an error code is displayed, eliminate error code and then verify pressure sensor needs adjustment.

All pressure transducer based flow stations and 1–5 VDC linear flow stations must be zeroed upon initial system set up. Linear 0–5 VDC flow stations do not require a zero flow to be established.

Adjusting the SUREFLOW™ controller calibration may be required to eliminate errors due to convection currents, HVAC configuration, or equipment used to make the measurement. TSI recommends always taking the comparison measurement in the exact same location (i.e., under the door, middle of door, edge of door, etc.). A thermal air velocity meter is needed to make the comparison measurement. Normally the velocity is checked at the crack under the doorway, or the door is opened 1” to allow alignment of the air velocity probe making the measurement. If the crack under the door is not large enough, use the 1” open door technique.

Calibrating Pressure Sensor

Enter calibration menu (see [Software Programming](#) if not familiar with key stroke procedure). Access code is turned on so enter proper access code. All menu items described below are found in SUPPLY FLOW menu.

Elevation

The ELEVATION item eliminates pressure sensor error due to elevation of building. (See ELEVATION item in [Menu and Menu items](#) section for further information).

Enter the ELEVATION menu item. Scroll through the elevation list and select the one closest to the building's elevation.

Press the **SELECT** key to save the data and exit back to the calibration menu.




Figure 7: Pressure Sensor Door Slid Open

Sensor span

NOTE: A smoke test and a comparison measurement by an air velocity meter are required to calibrate the pressure sensor. The air velocity meter only gives a velocity reading, so a smoke test must be performed to determine pressure direction.

WARNING: The span can only be adjusted in the same pressure direction. Adjusting span cannot cross zero pressure. Example: If unit displays +0.0001 and actual pressure is -0.0001 do not make any adjustments. Manually change the air balance, close or open dampers, or open door slightly to get both unit and actual pressure to read in same direction (both read positive or negative). This problem can only occur at very low pressures so slightly changing the balance should eliminate the problem.

Perform a smoke test to determine pressure direction.
 Select **SENSOR SPAN** item.
 Position thermal air velocity meter in door opening to obtain velocity reading. Press **▲/▼** keys until pressure direction (\pm) and sensor span match thermal air velocity meter, and smoke test.
 Press **SELECT** key to save sensor span.
 Exit menu, calibration is complete.

Flow Station Pressure Transducer Zero

NOTE: Not required for linear flow stations with 0-10 VDC output.

Pressure based flow station

Disconnect tubing between pressure transducer and flow station.
 Enter Supply Flow menu.
 Select **SP# FLO ZERO** to take a supply flow station zero.
 Press **SELECT** key. Flow zero procedure, which takes 10 seconds, is automatic.
 Press **SELECT** key to save data.
 Connect tubing between pressure transducer and flow station.

NOTE: #; insert number of flow station you are performing a zero on.

Linear flow station 1 to 10 VDC output

Remove flow station from duct, or cutoff flow in duct. Flow station must have no flow going past the sensor.

Enter Supply Flow menu.

Select SP# FLO ZERO to take a supply flow station zero.

Press **SELECT** key. Flow zero procedure, which takes 10 seconds, is automatic.

Press **SELECT** key to save data.

Install flow station back in duct.

NOTE: #; insert number of flow station you are performing a zero on.

2-Point Flow Calibration

Supply Flow Calibration:

Enter Supply Flow menu.

Select SP LOW SETP to enter a supply flow low calibration setpoint.

The DIM will display a value between 0% OPEN and 100% OPEN. Press the ▲ or ▼ keys to adjust the value displayed (and the damper position). Using a voltmeter, read the input voltage from the appropriate pressure transducer. When the voltmeter reading is approximately 20% of the full flow reading (100% OPEN) press the **SELECT** key to save the data.

then

Select SP HIGH SETP to enter a supply flow high calibration setpoint.

The DIM will display a value between 0% OPEN and 100% OPEN. Press the ▲ or ▼ keys to adjust the value displayed (and the damper position). Using a voltmeter, read the input voltage from the appropriate pressure transducer. When the voltmeter reading is approximately 80% of the full flow reading (100% OPEN) press the **SELECT** key to save the data.

then

Select SP# LOW CAL to enter a supply flow low calibration value.

The DIM will display two airflow values. Press the ▲ or ▼ keys to adjust the value displayed on the right to match the actual measured airflow, which is obtained with a duct traverse measurement or with a capture hood measurement.

Press **SELECT** key to save data.

then

Select SP# HIGH CAL to enter a supply flow high calibration value.

The DIM will display two airflow values. Press the ▲ or ▼ keys to adjust the value displayed on the right to match the actual measured airflow, which is obtained with a duct traverse measurement or with a capture hood measurement.

Press **SELECT** key to save data.

NOTE: A low flow calibration **must** be performed before its associated high flow calibration is performed. For example, in a laboratory that has two separate supply flows, **SP1 LOW CAL** must be completed before **SP1 HIGH CAL**. **SP2 LOW CAL** must be completed before **SP2 HIGH CAL**.

It is acceptable to complete all low flow calibrations before completing their associated high flow calibrations. To continue with the previous example: **SP1 LOW CAL** and **SP2 LOW CAL** could both be completed before completing **SP1 HIGH CAL** and **SP2 HIGH CAL**.

Calibrating temperature sensor

NOTE: Menu item is found in the **CALIBRATION** menu.

Enter the **TEMP CAL** item.

Use the **▲/▼** keys to adjust the current measured temperature value.

Press **SELECT** key to save data.

Maintenance and Repair Parts

The Model 8636 SUREFLOW™ Room Pressure Controller requires minimal maintenance. Periodic inspection of system components, as well as an occasional pressure sensor cleaning, is all that is needed to ensure that the Model 8636 is operating properly.

System Component Inspection

It is recommended that the pressure sensor be periodically inspected for accumulation of contaminants. The frequency of these inspections is dependent upon the quality of the air being drawn across the sensor. Quite simply, if the air is dirty, the sensors will require more frequent inspection and cleaning.

Visually inspect the pressure sensor by sliding open the sensor housing door (Figure 8). The air flow orifice should be free of obstructions. The small ceramic coated sensors protruding from the orifice wall should be white and free of accumulated debris.




Figure 8: Pressure Sensor Door Slid Open

Periodically inspect the other system components for proper performance and physical signs of excessive wear.

Pressure Sensor Cleaning

Accumulations of dust or dirt can be removed with a dry soft-bristled brush (such as an artist's brush). If necessary, water, alcohol, acetone, or trichlorethane may be used as a solvent to remove other contaminants.

Use extreme care when cleaning the velocity sensors. The ceramic sensor may break if excessive pressure is applied, if sensor is scraped to remove contaminants, or if the cleaning apparatus abruptly impacts the sensor.

WARNING: If you are using a liquid to clean the sensor, turn off power to the Model 8636. Do **NOT** use compressed air to clean the velocity sensors. Do **NOT** attempt to scrape contaminants from the velocity sensors. The velocity sensors are quite durable; however, scraping may cause mechanical damage and possibly break the sensor. Mechanical damage due to scraping voids the pressure sensor warranty.

Replacement Parts

All components of the room pressure controller are field replaceable. Contact TSI HVAC Control Products at (800) 874-2811 (U.S. and Canada) or (001 651) 490-2811 (other countries) or your nearest TSI Manufacturer's Representative for replacement part pricing and delivery.

Part Number	Description
800775	Pressure Controller
800778	Pressure Controller w/LON
863619	Pressure Controller w/BACnet [®] MSTP
800326	Pressure Sensor
800248	Sensor Cable
800414	Transformer Cable
800420	Transformer
800199	Controller Output Cable
800360	Electric Actuator

Troubleshooting Section

The SUREFLOW™ Room Pressure Controller is designed to be trouble free. However, installation problems or interaction with other HVAC components may cause system problems. The SUREFLOW™ system is easy to trouble shoot if an organized approach to evaluate the system is taken. Troubleshooting is broken down into hardware and software problems. Hardware problems deal with the physical installation of the device. Hardware problems include wiring problems, incorrectly installed equipment, and add-ons or non-TSI equipment. Software problems include control problems, configuration problems, or interaction problems with the HVAC system.

The hardware test described in this section determines that all TSI mechanical components are functioning correctly. The hardware test requires the diagnostics menu items to be accessed. If you are unfamiliar with the SUREFLOW™ controller menus, see [Software Programming](#) for keystroke procedure. Troubleshooting the majority of problems is usually quick if the hardware test is followed.

Software and hardware problems are covered in the troubleshooting chart. Pick the problem that most closely resembles your problem and review the possible symptoms and corrective action. Software or system performance problems can and are affected by the supply air system, exhaust air system, or physical configuration of the room. Separating TSI system problems from the HVAC system can sometimes be difficult. TSI recommends confirming all hardware is operating correctly before troubleshooting software problems.

Hardware Test

Three tests need to be performed in order to determine all hardware is functioning correctly. The tests are broken down into:

- Confirming wiring is correct.
- Confirming physical installation is correct.
- Verifying mechanical components.

Confirming wiring is correct

The most common problem with installed hardware equipment is incorrect wiring. This problem usually exists on initial installation, or when modifications to the system take place. The wiring should be very closely checked to verify it *exactly* matches the wiring diagram. The TSI cables are all color coded to ensure proper wiring. A wiring diagram is located in [Appendix B](#) of this manual. Wiring associated with non TSI components should be closely checked for correct installation. If non TSI components are installed, consider disconnecting them for testing purposes.

Confirming physical installation is correct

All of the hardware components need to be installed properly. Review the installation instructions and verify components are installed properly at the correct location. This is easily done when the wiring is checked.

Verifying mechanical components

Verifying all TSI components are operating correctly requires following a simple procedure. The fastest procedure to confirm all equipment is operating is to first test the DIM, and then go into the diagnostic menu to test each component.

NOTE: These tests require power to the units, so if unit has no power, refer to hardware troubleshooting chart to eliminate power problem.

TEST - DIM

Press **TEST** key to verify Digital Interface Module (DIM) electronics are functioning correctly. At the end of the self test, the display will show **SELF TEST - PASSED** if all DIM electronics are good. If unit displays **DATA ERROR** at the end of the test, the electronics may be corrupted. Check all software items to determine cause of **DATA ERROR**.

If **SELF TEST - PASSED** is displayed proceed to test individual components. Enter [Diagnostics Menu](#) and check the following:

- Control output - supply.
- Control output - exhaust.
- Control output - temperature.
- Sensor input.
- Sensor status.
- Supply flow stations.
- Temperature input.

NOTE: Skip any test that does not have option installed.

These diagnostic menu items are explained in detail in the next section ([Diagnostics Menu](#)) of the manual, so their function is not reviewed here. If the SUREFLOW™ system passes each of the tests, the mechanical piece parts are all functioning correctly.

TEST - Control output - supply

Enter **CONTROL SUP** menu item in diagnostics menu. A number between 0 and 255 will be displayed. Press the ▲/▼ keys until either 0 or 255 shows on the display. Note the position of the supply air control damper. If display reads 0, press the ▲ key until 255 is shown on display. If display read 255 press ▼ key until 0 is shown on display. Note the position of the supply air damper. The damper should have rotated either 45 or 90 degrees depending on actuator installed. If not, see the hardware section [Control system is not controlling](#).

TEST - Control output - exhaust

Enter **CONTROL EXH** menu item in diagnostics menu. A number between 0 and 255 will be displayed. Press the ▲/▼ keys until either 0 or 255 shows on the display. Note the position of the general exhaust control damper. If display reads, 0 press the ▲ key until 255 is shown on display. If display read 255 press ▼ key until 0 is shown on display. Note the position of the general exhaust damper. The damper should have rotated either 45 or 90 degrees depending on actuator installed. If not, see the hardware section [Control system is not controlling](#).

TEST - Control output - temperature

Enter **CONTROL TEMP** menu item in diagnostics menu. A number between 0 and 255 will be displayed. Press the ▲/▼ keys until either 0 or 255 shows on the display. Note the position of the reheat valve. If display reads 0, press the ▲ key until 255 is shown on display. If display read 255 press ▼ key until 0 is shown on display. Note the position of the reheat valve. The damper should have moved through its full stroke. If not, see hardware section [Control system is not controlling](#). Reheat valves typically move slowly, so you may have to wait to see the full motion.

TEST - Sensor input

Enter **SENSOR INPUT** menu item in diagnostics menu. A voltage between 0 and 10 volts DC will be displayed. It is not important what the exact voltage is to pass this test. Tape over the pressure sensor (slide pressure sensor door open) and voltage should read

approximately 5 volts (zero pressure). Remove tape and blow on sensor. Displayed value should change. If voltage changes, the unit passes. If voltage doesn't change, proceed to TEST - Sensor status.

TEST - Sensor status

Enter SENSOR STAT menu item in diagnostics menu. If NORMAL is displayed, the unit passes test. If an error message is displayed, go to diagnostics menu section of the manual, SENSOR STAT menu item for explanation of error message.

TEST - Supply flow station

Enter SUP FLOW IN menu item in diagnostics menu. A voltage between 0 and 10 volts DC will be displayed. The exact voltage displayed is not important as long as the voltage varies as flow changes. Zero volts equals no flow while 10 volts is maximum flow. After calibration, the signal establishes a correlation between flow and voltage.

TEST - Temp input

Enter TEMP INPUT menu item in diagnostics menu. A temperature will be displayed. The exact temperature displayed is not important as long as the temperature changes when the RTD signal changes.

If unit passed all tests, the mechanical components are physically working. If problems still exist, go to troubleshooting chart for additional information, on both hardware and software symptoms.

Diagnostics Menu

The items in the diagnostic menu aid in identifying problems the staff may encounter. The items in this menu temporarily change the function by pressing the ▲/▼ keys. No permanent change occurs with these menu items. Items are exited by pressing the **MENU** key. When an item is exited the SUREFLOW™ controller returns to its normal state.

Supply Air Control Output

Menu item - CONTROL SUP

The CONTROL SUP item is used to change the control output signal to the supply air actuator/damper (or motor speed drive). When this item is entered, a number will be shown on the display indicating the last control output value. The range of values displayed is 0 - 255. Pressing the ▲/▼ keys change the count on the display. Pressing the ▲ key should increase the displayed value, while pressing the ▼ key will decrease the displayed value. The supply control device should change (modulate) as the number changes. Depending on the jumper location on the actuator, 0 or 255 is full open on damper. Conversely 255 or 0 will be full closed. A count of 150 should position the damper approximately 1/2 open. On units controlling variable frequency drives, fan speed should increase or decrease as numbers change.

WARNING: The CONTROL SUP function overrides the pressure control signal. Adequate room pressure will **not** be maintained while in this item.

Exhaust Air Control Output

Menu item - CONTROL EXH

The CONTROL EXH item is used to change the control output signal to the exhaust supply air actuator/damper (or motor speed drive). When this item is entered, a number will be shown on the display indicating the last control output value. The range of values displayed is 0 - 255. Pressing the ▲/▼ keys change the count on the display. Pressing the ▲ key should increase the displayed value, while pressing the ▼ key will decrease the displayed value. The exhaust control device should change (modulate) as the number changes. Depending on the jumper location on the actuator, 0 or 255 is full open on damper. Conversely 255 or 0 will be full closed. A count of 150 should position the

damper approximately 1/2 open. On units controlling variable frequency drives, fan speed should increase or decrease as numbers change.

WARNING: The CONTROL EXH function overrides the pressure control signal. Adequate room pressure will NOT be maintained while in this item.

Temperature Control Output

Menu item - CONTROL TEMP

The CONTROL TEMP item is used to change the control output signal to the reheat valve actuator. When this item is entered, a number will be shown on the display indicating the last control output value.

The range of values displayed is 0 - 255. Pressing the ▲/▼ keys change the count on the display. Pressing the ▲ key should increase the displayed value, while pressing the ▼ key will decrease the displayed value. The reheat valve actuator should change (modulate) as the number changes. Depending on the actuator, 0 or 255 is full open on damper. Conversely 255 or 0 will be full closed. A count of 150 should position the valve approximately 1/2 open.

WARNING: The CONTROL TEMP function overrides the temperature control signal. Adequate room temperature will **not** be maintained while in this item.

Sensor Input

Menu item - SENSOR INPUT

The SENSOR INPUT item is used to verify that the DIM or controller electronics is receiving a signal from the sensor. When this item is entered, a voltage will be indicated on the display. The exact voltage displayed is relatively unimportant. It is more important that the voltage is changing which indicates the sensor is working correctly.

0 volts represents a negative pressure of -0.2 inches H₂O.

5 volts represents 0 pressure

10 volts represents a positive pressure of +0.2 inches H₂O.

Sensor Communications

Menu Item - SENSOR STAT

The SENSOR STAT item verifies that the RS-485 communications between the pressure sensor and DIM is working correctly. Sensor error messages do not display on DIM except when SENSOR STAT item is selected. The item will display NORMAL if communications are established correctly. If problems exist, one of four error messages will display:

COMM ERROR - DIM cannot communicate with sensor. Check all wiring and the pressure sensor address. Address must be 1.

SENS ERROR - Problem with sensor bridge. Physical damage to pressure sensor or sensor circuitry. Unit is not field repairable. Send to TSI for repair.

CAL ERROR - Calibration data lost. Sensor must be returned to TSI to be calibrated.

DATA ERROR - Problem with EEPROM, field calibration, or analog output calibration lost. Check all data programmed and confirm unit is function correctly.

Switch Input

Menu Item - SWITCH INPUT

The SWITCH INPUT item reads the input of the SWITCH IN contact pins 11 and 12. When this item is entered, the display will indicate either open or closed. If the display indicates open, the DIM is in SETPOINT and ALARM DELAY mode. If the display indicates closed, the DIM is in REM SETPOINT and DOOR DELAY mode. SWITCH INPUT changes both pressure setpoint and alarm delay when closed. If the same setpoint or alarm delay is required, set both setpoints or alarm delay to same value.

Unoccupied switch Input

Menu Item - UNOCC INPUT

The UNOCC INPUT item reads the input of the UNOCC IN contact pins 19 and 20. When this item is entered, the display will indicate either open or closed. If the display indicates open, the DIM is in VENT MIN SET and TEMP MIN SET mode. If the display indicates closed, the DIM is in UNOCC SETP mode.

Supply Flow Input

Menu Item – SUP1 FLOW IN & SUP2 FLOW IN*

The SUP# FLOW IN item is used to read the input from the supply flow station. When this item is entered, a voltage will be indicated on the display. The exact voltage displayed is relatively unimportant. It is more important that the voltage is changing which indicates the flow station is working correctly.

This item is a diagnostics tool used to compare the supply flow to a traverse of the duct work. If flow error is greater than 10%, calibrate the flow station.

*This menu items does not appear on Model 8636 SUREFLOW™ controllers provided with the optional LonWorks® communication board.

Temperature Input

Menu Item - TEMP INPUT

The TEMP INPUT item is used to read the input from the sensor. When this item is entered, a temperature will be indicated on the display. The exact temperature displayed is relatively unimportant. It is more important that the temperature is changing which indicates the sensor is working correctly.

Low Alarm Relay


Menu Item - ALARM RELAY

The ALARM RELAY item is used to change the state of the alarm relay. When this item is entered, the display will indicate either OPEN or CLOSED. The ▲/▼ keys are used to toggle the state of the relay. The ▲ key is used to OPEN the alarm contact. The ▼ key is used to CLOSE the alarm contact. When the contact is closed, the ALARM RELAY should be in an alarm condition.

Troubleshooting Chart

Symptom	Possible Cause	Corrective Action
Display is blank.	Fuse is blown.	<p>Measure voltage at pins 1 and 2 on DIM. The voltage should nominally be;</p> <ul style="list-style-type: none"> 24 to 40 VDC when using TSI electric actuators 24 to 30 VAC when using TSI pneumatic actuators 24 to 30 VAC when using motor speed drives. <p>If correct voltage is measured, internal DIM fuse is probably blown. Unplug 14-pin connector from DIM for 2 minutes. The internal fuse will automatically reset. Plug unit back in and check display. If display is still blank, check all wiring, etc. If no problems are found, replace DIM.</p> <p>If approximately 5 volts is measured, the fuse in the electric actuator or E/P is blown. Disconnect power to the electric actuator or E/P for two minutes to reset fuse. Disconnecting power requires either shutting off circuit breaker or disconnecting the wires on pins 1 and 2 on the electric actuator or E/P.</p> <p>If zero volts are measured, see No power to DIM.</p>
	No power to DIM.	<p>Verify circuit breaker is on. Verify transformer primary measures 110 VAC. Verify transformer secondary measures 24 to 30 VAC. Verify electric actuator or E/P interface is receiving 24 to 30 volts between pins 1 and 2. Verify 24 to 40 VDC is found between pins 3 and 4 of the electric actuator. Verify 24 to 30 VAC between pins 3 and 4 of the E/P interface. Verify voltage on pins 1 and 2 of DIM is 24 to 30 VAC for pneumatic systems and VFDs, or 24 to 40 VDC on electric actuators.</p>
	DIM is defective.	<p>If proper voltage is found between pins 1 and 2 of the DIM, all wiring has been checked, fuses have been reset, and screen is still blank, the DIM is probably defective. Replace DIM.</p>
Control system is not controlling.	Incorrect wiring.	<p>Verify correct wiring (see wiring diagram, Appendix B). DIM must be wired exactly as shown.</p>
	Supply and exhaust control wiring reversed.	<p>Verify supply control wiring (pins 17 and 18) goes to supply damper and exhaust control wiring (pins 9 and 10) goes to general exhaust damper.</p>

Symptom	Possible Cause	Corrective Action
Control system is not controlling. (continued)	No control output signal.	<p>Go into DIAGNOSTICS menu, CONTROL SUP or CONTROL EXH item. A number between 0 and 225 will be displayed. Pressing the ▲ key increases the number. Pressing the ▼ key decreases the number. Measure the DC voltage between pins 17 and 18 on the controller. Change the CONTROL value about 100 numbers. The voltage output should change approximately 4 volts. Change the CONTROL value to 150. The voltage should read approximately 5 VDC.</p> <p>If no change occurs, disconnect control wires on pins 17 and 18 and repeat test. If DIM still fails to change voltage output, DIM is probably defective.</p>
	Bad actuator or E/P (damper doesn't move).	<p>Go into DIAGNOSTICS menu, CONTROL SUP or CONTROL EXH item. A number between 0 and 255 will be displayed. Pressing the ▲ key increases the number. Pressing the ▼ key decreases the number. Change the CONTROL value to read 0 or 255. Note damper position. Press an arrow key to change 0 to 255 or 255 to 0. Note position of damper. Damper should have rotated 45 or 90 degrees depending on actuator system installed.</p> <p>If damper rotated 45 or 90 degrees, actuator is installed and operating correctly. If damper did not rotate, check that:</p> <ul style="list-style-type: none"> • Jumper is installed correctly on actuator or E/P. (Appendix B) • Damper is not physically stuck (screws, etc.). • Wiring is correct between actuators and controller. Check that voltage varies between 0 and 10 volts on pins 6 and 7 on electric actuator or E/P (see No control output signal). • Electric actuator is not over torqued. The electric actuator has current limiting protection. If damper is physically stuck or actuator is over current, the actuator will shut down. To restart either kill power to actuator or move damper in opposite direction it was trying to rotate (CONTROL SUP or CONTROL EXH menu item).
	Defective variable frequency drive (VFD).	<p>Perform test described in Control system is not controlling. If CONTROL OUT is functioning, verify wiring to VFD by confirming CONTROL OUT voltage changes at VFD. If voltage changes, a problem with VFD exists. See VFD manual for further troubleshooting.</p>
	Damper rotating opposite direction.	<p>If damper is full open when it should be closed or full closed when it should be open, go into CONTROL menu CONTROL SIG menu item. Change direct to reverse or reverse to direct to change control output direction. The control sig changes the direction of both the supply and exhaust damper. If only 1 damper rotates incorrectly, change the jumper on the E/P or electric actuator.</p>

Symptom	Possible Cause	Corrective Action
Control system is not controlling (continued)	Damper is full open or full closed, won't move.	Actuator jumper is missing or loose. Verify jumper is installed correctly. Control wires are loose. Check wires and verify control output is working (see no control output signal). If control output test passes, verify damper is rotating correct direction (see damper rotating opposite direction). If damper is rotating correctly and setpoint cannot be reached, DIM will fully rotate damper to get as close to setpoint as possible. Air balance needs to be adjusted.
Sensor does not calibrate.	Sensor communications not working.	Check SENSOR STAT item in diagnostics menu. If NORMAL is displayed, sensor is okay, if COMM ERROR is displayed, check wiring, pressure sensor address, and that DIP switch 1 & 2 are ON (Figure 9).
		
	Incorrect pressure sensor address.	Pressure sensor must have address of 1. Check pressure sensor DIP switches 5 & 6 and verify address 1 is correct (7-12 must be OFF).
Pressure sensor red LED is blinking (Figure 9).	<p>Problem with sensor (slow uniform blink).</p> <p>Communication (fast burst of non-uniform blinking).</p> <p>Red LED is constantly on.</p>	<p>Check SENSOR STAT and confirm NORMAL is displayed. If ERROR is displayed, correct error.</p> <p>Unit is communicating with DIM. This is normal.</p> <p>This is normal when no problems exist or when no communication is occurring.</p>

Symptom	Possible Cause	Corrective Action
DIM always displays 0.200 inches H ₂ O.	Incorrect pressure sensor output.	Pressure sensor must be set for 0-10 volt output, not 4–20 mA. Check pressure sensor DIP switch 3 and make sure it is OFF (see Figure 9).
DIM does not respond to RS-485 communications.	Network protocol is incorrect. Incorrect network address. Incompatible software.	Go into INTERFACE menu, NET PROTOCOL item. The protocol must match host system. Select correct interface. The network address at the building automation system and at the DIM must match. The network address must be unique for each DIM. Data sent to DIM may be in form that the SUREFLOW™ controller cannot recognize.
DIM displays opposite pressure signal.	Sensor direction is incorrect.	Pressure sensor must have DIP switch correctly set for proper sign display. Verify DIP switch 4 is ON when sensor is mounted in the laboratory (controlled space), and OFF when sensor is mounted in corridor (reference space). See Figure 9.
Alarm relays don't work.	Alarms are turned off. Incorrect wiring. Relay may be defective.	Press TEST key. The individual alarm setpoints will display. If all alarm setpoints are zero, alarm relay is not active, so relay will not be required to change state. Check the wiring from SUREFLOW™ controller relay's output to the device that is connected to the relays. Disconnect the wiring from relay contact pins 13 and 14 for low alarm relay and pins 25 and 26 for high alarm relay. Go into DIAGNOSTICS menu, LOW ALM REL or HIGH ALM REL. Connect an ohmmeter to relay terminals to verify contact open and closes. Press the ▲/▼ keys to manually trip the relay. If relay responds (contact opens and closes), the device connected is incompatible or defective. If relay doesn't respond, relay is defective (may be caused by incompatible device). Replace DIM.
"DATA ERROR" flashing on display.	DIM was hit by electrical disturbance.	All data may be lost or changed. Review all configuration parameters. DATA ERROR is removed by pressing the RESET key.
Actuator hunting. Display indicates steady pressure.	Control system is unstable.	Go into CONTROL menu, SPEED item. Turn speed down until hunting is eliminated. If speed is too slow review CONTROL menu items and adjust accordingly to eliminate hunting.

Symptom	Possible Cause	Corrective Action
Displayed pressure wildly fluctuating.	Control system is unstable.	Go into CONTROL menu SPEED item, turn speed down until fluctuation is eliminated. If speed is too slow, review CONTROL menu items and adjust accordingly until performance is adequate.
	Exhaust system unstable.	Turn DIM to emergency. If pressure stabilizes, this is not the problem. Verify reference pressure is not fluctuating.
	Supply or exhaust air is affecting the sensor.	Check location of supply air diffusers and exhaust grilles. They should be as far from pressure sensor as is realistic, 6 feet preferred, 2-1/2 feet minimum. Supply diffuser terminal throw velocity must be less than 10 ft/min at the sensor. Relocate supply or exhaust as needed.
Temperature not controlling	Incorrect wiring.	Verify correct wiring (see wiring diagram, Appendix B). DIM must be wired exactly as shown.
	No control output signal.	Go into DIAGNOSTICS menu, CONTROL SUP or CONTROL EXH item. A number between 0 and 225 will be displayed. Pressing the ▲ key increases the number. Pressing the ▼ key decreases the number. Measure the DC voltage between pins 25 and 26 on the controller. Change the CONTROL value about 100 numbers. The voltage output should change approximately 4 volts. Change the CONTROL value to 150. The voltage should read approximately 5 VDC. If no change occurs, disconnect control wires on pins 25 and 26 and repeat test. If DIM still fails to change voltage output, DIM is probably defective.
	Bad actuator (valve doesn't move).	Go into DIAGNOSTICS menu, CONTROL TEMP. A number between 0 and 255 will be displayed. Pressing the ▲ key increases the number. Pressing the ▼ key decreases the number. Change the CONTROL value to read 0 or 255. Note valve position. Press an arrow key to change 0 to 255 or 255 to 0. Note position of valve. Valve should have moved full stroke.
	Valve rotating opposite direction.	If Valve is full open when it should be closed or full closed when it should be open, go into CONTROL menu TEMP CONTROL menu item. Change direct to reverse or reverse to direct to change control output direction.

Appendix A

Specifications

Room Pressure Module

Display

Range	-0.20000 to +0.20000 inches H ₂ O
Accuracy	±10% of reading, ±0.00001 inches H ₂ O
Resolution	5% of reading
Display Update.....	0.5 sec

Inputs

Switch in	SPST (N.O.) Switch. Closing switch initiates condition.
Unoccupied switch in.....	SPST (N.O.) Switch. Closing switch initiates condition.
Flow in	0 to 10 VDC
Temperature In	1000Ω platinum RTD (TC: 385 Ω/100 °C)

Outputs

Supply Control	0 to 10 VDC
Exhaust Control.....	0 to 10 VDC
Reheat Control	0 to 10 VDC or 4 to 20 mA
Low Alarm Range	-0.19500 to +0.19500 inches H ₂ O
High Alarm Range	-0.19500 to +0.19500 inches H ₂ O
Alarm Contact	SPST (N.O.) Max current 2A Max voltage 220 VDC Maximum power 60 W Contacts close in alarm condition
RS-485	Modbus RTU standard, N2 optional
LON	Optional
BACnet [®] MSTP	Model 8636-BAC only

General

Operating Temperature	32 to 120°F
Internal Scan Rate	50 msec
Input Power	24 VAC, 5 watts max @ 50 or 60 Hz 24 VDC @ 50 or 60 Hz
Dimensions (HWD)	4.9 in. × 4.9 in. × 1.35 in.
Weight.....	0.7 lb.

Pressure Sensor

Temperature Compensation Range	55 to 95°F
Power Dissipation	0.16 watts at 0 inches H ₂ O, 0.20 watts at 0.00088 inches H ₂ O
Dimensions (HWD)	3.34 in. × 5.58 in. × 1.94 in.
Weight.....	0.2 lb.

Damper/Actuator

Type of Actuators.....	Electric
Input Power	Electric: 24 VAC
Time for 90° Rotation	Electric: 1.5 seconds

Appendix B

Network Communications

Network communications are available on the Model 8636 and Model 8636-BAC. The Model 8636 can communicate with a building management system through Modbus or LonWorks[®] protocols. The Model 8636-BAC can communicate with a building management system through BACnet[®] MSTP. Please refer to the appropriate section below for more detailed information.

Modbus Communications

Modbus communications are installed in all Model 8636 laboratory room pressure controllers and monitors. This document provides the technical information needed to communicate between the host DDC system and the Model 8636 units. This document assumes the programmer is familiar with Modbus protocol. Further technical assistance is available from TSI if your question is related to TSI interfacing to a DDC system. If you need further information regarding Modbus programming in general, please contact:

Modicon Incorporated
One High Street
North Andover, MA 01845
Phone (800) 468-5342

The Modbus protocol utilizes the RTU format for data transfer and Error Checking. Check the Modicon Modbus Protocol Reference Guide (PI-Mbus-300) for more information on CRC generation and message structures.

The messages are sent at 9600 baud with 1 start bit, 8 data bits, and 2 stop bits. Do not use the parity bit. The system is set up as a master slave network. The TSI units act as slaves and respond to messages when their correct address is polled.

Blocks of data can be written or read from each device. Using a block format will speed up the time for the data transfer. The size of the blocks is limited to 20 bytes. This means the maximum message length that can be transferred is 20 bytes. The typical response time of the device is around 0.05 seconds with a maximum of 0.1 seconds.

Unique to TSI

The list of variable addresses shown below skips some numbers in the sequence due to internal Model 8636 functions. This information is not useful to the DDC system and is therefore deleted. Skipping numbers in the sequence will not cause any communication problems.

All variables are outputted in English units: ft/min, CFM, or inches H₂O. The room pressure control setpoints and alarms are stored in ft/min. The DDC system must convert the value to inches of water if that is desired. The equation is given below.

$$\text{Pressure in Inches H}_2\text{O} = 6.2 \times 10^{-8} \times (\text{Velocity in ft/min} / .836)^2$$

RAM Variables

RAM variables use the Modbus command **04 Read Input Registers**. RAM variables are read only variables that correspond to what is shown on the Digital Interface Module (DIM) display. TSI offers a number of different models, so if a feature is not available on a unit, the variable is set to 0.

8636 Laboratory Room Pressure Controller RAM Variable List

Variable Name	Variable Address	Information Provided to Master System	Integer DDC system receives
Velocity	0	Velocity of room pressure	Displayed in feet per minute.
Pressure	1	Room pressure	Displayed in inches H ₂ O. Host DDC system must divide value by 100,000 to report pressure correctly.
Total Supply Flow Rate	2	Total flow (CFM) measured by the Supply #1 and Supply #2 duct flow station	Displayed in CFM.
Supply #1 Flow Rate	3	Flow (CFM) measured by the Supply #1 duct flow station	Displayed in CFM.
Supply #2 Flow Rate	4	Flow (CFM) measured by the Supply #2 duct flow station	Displayed in CFM.
Setpoint	5	Current control setpoint	Displayed in feet per minute.
Status Index	6	Status of SUREFLOW™ device	0 Normal 1 Low Alarm 2 High Alarm 4 Min Sup Alm 7 Data Error 8 Emergency
Control Mode	7	Control mode device is in	0 = Main 1 = Door
Current Temperature	8	Current space temperature	Displayed in °F. Host DDC system must divide value by 10 to report temperature correctly.
Exhaust Control Signal	14	Exhaust damper position	0-100% Open
Supply Control Signal	15	Supply damper position	0-100% Open
Temperature Control Signal	16	Reheat valve position	0-100% Open

EXAMPLE of **04 Read Input Registers** function format.
This example read variable addresses 0 and 1 (Velocity and Pressure from 8636).

QUERY		RESPONSE	
Field Name	(Hex)	Field Name	(Hex)
Slave Address	01	Slave Address	01
Function	04	Function	04
Starting Address Hi	00	Byte Count	04
Starting Address Lo	00	Data Hi Addr0	00
No. Of Points Hi	00	Data Lo Addr0	64 (100 ft/min)
No. Of Points Lo	02	Data Hi Addr1	00
Error Check (CRC)	--	Data Lo Addr1	59 (.00089" H ₂ O)
		Error Check (CRC)	--

XRAM Variables

These variables can be *read* using Modbus command **03 Read Holding Registers**. They can be *written* to using Modbus command **16 Preset Multiple Regs**. Many of these variables are the same “menu items” that are configured from the SUREFLOW™ controller keypad. The calibration and control items are not accessible from the DDC system. This is for safety reasons, since each room is individually setup for maximum performance. TSI offers a number of different models, so if a feature is not available on a unit, the variable is set to 0.

8636 Laboratory Room Pressure Controller XRAM Variable List

Variable Name	Variable Address	Input Provided to Master System	Integer DDC system receives
Software Version (read only)	0	Current software version	Host DDC system must divide value by 100 to report software version correctly.
Control Device (read only)	1	SUREFLOW™ Model	6 = Lab Controller
Emergency Mode	2	Emergency Mode Control	0 = Leave emergency mode 1 = Enter emergency mode Value will return a 2 when read
Setpoint	3	Pressure control setpoint	Displayed in feet per minute.
Remote Setpoint	4	Remote pressure control setpoint	Displayed in feet per minute.
Minimum Unoccupied Setpoint	5	Minimum supply flow in unoccupied mode.	Displayed in CFM.
Minimum Ventilation Supply Flow Setpoint	6	Minimum supply flow control setpoint in normal mode.	Displayed in CFM.
Cooling Flow Supply Flow Setpoint	7	Minimum supply flow control setpoint in temperature mode.	Displayed in CFM.
Temperature Setpoint	8	Space temperature setpoint	Displayed in °F. Host DDC system must divide value by 10 to report temperature correctly.
Unoccupied Temperature Setpoint	9	Space temperature setpoint	Displayed in °F. Host DDC system must divide value by 10 to report temperature correctly.
Low Alarm Setpoint	10	Low pressure alarm setpoint	Displayed in feet per minute.
High Alarm Setpoint	11	High pressure alarm setpoint	Displayed in feet per minute.
Remote Low Alarm Setpoint	12	Remote mode low pressure alarm setpoint	Displayed in feet per minute.
Remote High Alarm Setpoint	13	Remote mode high pressure alarm setpoint	Displayed in feet per minute.
Min Supply Alarm	14	Minimum supply flow alarm	Displayed in CFM.
Alarm Mode	15	Latched or Unlatched alarms	0 = Unlatched 1 = Latched
Audible Alarm	16	Audible alarm indication	0 = Off 1 = On

8636 Laboratory Room Pressure Controller XRAM Variable List (continued)

Variable Name	Variable Address	Input Provided to Master System	Integer DDC system receives
Alarm Delay	17	Time delay before activation of audible alarm, after entering alarm condition.	20 to 600 seconds. Host DDC system must divide value by 10 to report alarm delay correctly
Door Delay	18		20 to 600 seconds. Host DDC system must divide value by 10 to report alarm delay correctly
Mute Delay	19	Length of time alarm is muted when mute key is pressed	300 to 1800 seconds. Host DDC system must divide value by 600 to report alarm delay correctly.
Units Value	20	Current pressure units displayed	0 = Feet per minute 1 = meters per second 2 = inches of H ₂ O 3 = Pascal

EXAMPLE of **16 (10 Hex) Preset Multiple Regs** function format:

This example changes the remote setpoint to 100 ft/min.

QUERY

Field Name	(Hex)
Slave Address	01
Function	10
Starting Address Hi	00
Starting Address Lo	04
No. Of Registers Hi	00
No. Of Registers Lo	01
Data Value (High)	00
Data Value (Low)	64
Error Check (CRC)	--

RESPONSE

Field Name	(Hex)
Slave Address	01
Function	10
Starting Address Hi	00
Starting Address Lo	04
No. of Registers Hi	00
No. of Registers Lo	01
Error Check (CRC)	--

Example of **03 Read Holding Registers** function format:

This example reads the minimum ventilation setpoint and the minimum temperature setpoint.

QUERY

Field Name	(Hex)
Slave Address	01
Function	03
Starting Address Hi	00
Starting Address Lo	05
No. Of Registers Hi	00
No. Of Registers Lo	02
Error Check (CRC)	--

RESPONSE

Field Name	(Hex)
Slave Address	01
Function	03
Byte Count	04
Data Hi	03
Data Lo	8E (1000 CFM)
Data Hi	04
Data Lo	B0 (1200 CFM)
Error Check (CRC)	

LonWorks® Node Object

Node Object Network Variables				
Number	Bit	Name	Description	Type
1		nviRequest		SNVT_obj_request
2		nviSetTime		SNVT_time_stamp
3		nviMute		SNVT_switch
4		nviStatus		SNVT_obj_status
5		nviAlarm		SNVT_alarm
6		nvoControlStatus		SNVT_char_ascii
	0		Standard	
	1		Unoccupied	
	2		Remote Setpoint	
7		nvoStatusIndex		SNVT_char_ascii
	0		Normal	
	2		Low Alarm	
	3		High Alarm	
	4		Minimum Supply Alarm	
	5		Second Sensor Low Alarm	
	6		Second Sensor High Alarm	
	7		Data Error	
	8		Emergency	
	9		LON Override	
		nciOutInht		
		nciDeviceIndex		
		nciFirmwareVer		

LonWorks® Object

Direct Pressure Controller Object Network Variables				
Number	Bit	Name	Description	Type
1		nviSpaceTemp		SNVT_temp_p
2		nviControlMode		SNVT_occupancy
3		nviEmergMode		SNVT_hvac_emerg
4		nviExhOverride		SNVT_hvac_overrid
5		nviSupOverride		SNVT_hvac_overrid
6		nviRehtOverride		SNVT_hvac_overrid
7		nviDoorSwitch		SNVT_switch
8		nviSpaceTempSet		SNVT_temp_p
9		nviRmPressSet*		SNVT_press_f
10		nvoRoomPress		SNVT_press_f
11		nvoSpaceTemp		SNVT_temp_p
14		nvoTotSupFlo		SNVT_flow
15		nvoSupDamperPos		SNVT_lev_percent
16		nvoExhDamperPos		SNVT_lev_percent
17		nvoRehtValvePos		SNVT_lev_percent
18		nvoRmPressSet		SNVT_press_f
19		nvoMinSupFloSet		SNVT_flow
21		nvoUnOccFloSet		SNVT_flow
24		nvoCoolSupFlo		SNVT_flow
25		nvoDoorPressSet		SNVT_press_f
33		nvoLoPressAlm		SNVT_press_f
34		nvoHiPressAlm		SNVT_press_f
		nciMinSendTime		
		nciSndDeltaFlow		
		nciSndDeltaPress		
		nciSndDeltaTemp		
		nciSndDeltaPos		

*Pressure values must be multiplied by 1000 when writing to nviRmPressSet. For example, write -2.50 for a pressure value of -.00250 in. H₂O.

Description of LON SNVTs

SNVT	Command Supported	Action
nviEmergMode:	EMERG_NORMAL EMERG_PURGE	Sets NORMAL mode Sets EMERGENCY mode

Note: all other commands set NORMAL mode

SNVT	Command Supported	Action
nviControlMode:	OC_OCCUPIED OC_STANDBY OC_UNOCCUPIED	Sets NORMAL mode Sets SETBACK mode Sets SETBACK mode

Note: all other commands set NORMAL mode

SNVT	Command Supported	Action
nviExhOverride nviSupOverride nviRehtOverride	NVO_OFF NVO_POSITION NVO_MAXIMUM NVO_MINIMUM	Clears override Moves the damper/valve (0 % - 100% open) Moves damper /valve to 100% open Moves damper/valve to 0% open

Note: all other commands set NORMAL mode

SNVT	Command Supported	Action
nviRequest object_request	CLEAR_ALARM	Clears alarm

8636 BACnet[®] MS/TP Protocol Implementation Conformance Statement

Date: April 26, 2007

Vendor Name: TSI Inc.

Product Name: Pressura Room Pressure Controller

Product Model Number: 8636-BAC

Applications Software Version: 1.0

Firmware Revision: 1.0

BACnet Protocol Revision: 2

Product Description:

TSI SUREFLOW™ Room Pressure Controls are designed to actually measure the room pressure differential used to prevent chemical vapors from escaping outside the lab. This controller will modulate supply and general exhaust air flows to maintain laboratory ventilation and the room pressure differential, to comply with standards such as NFPA45-2000 and ANSI Z9.5-2003. This controller also controls the temperature of the laboratory space, by modulating the reheat and the supply air volume. This model controller is capable of acting as a stand-alone device or as part of a building automation system via BACnet MS/TP protocol.

BACnet Standardized Device Profile (Annex L):

- BACnet Operator Workstation (B-OWS)
- BACnet Building Controller (B-BC)
- BACnet Advanced Application Controller (B-AAC)
- BACnet Application Specific Controller (B-ASC)
- BACnet Smart Sensor (B-SS)
- BACnet Smart Actuator (B-SA)

List all BACnet Interoperability Building Blocks Supported (Annex K):

DS-RP-B	DM-DDB-B
DS-WP-B	DM-DOB-B
DS-RPM-B	DM-DCC-B

Segmentation Capability:

Segmented requests not supported
Segmented responses not supported

Standard Object Types Supported:

	Dynamically Createable	Dynamically Deletable	Optional Properties Supported	Writable Properties (Data Type)
Analog Input	No	No		
Analog Value	No	No		Present_Value (Real)
Binary Input	No	No	Active_Text, Inactive_Text	
Binary Value	No	No	Active_Text, Inactive_Text	Present_Value (Enumerated)
Multi-state Input	No	No	State_Text	
Multi-state Value	No	No	State_Text	Present_Value (Unsigned Int)
Device Object	No	No		Object Name (Char String) Max Master (Unsigned Int)

Data Link Layer Options:

- BACnet IP, (Annex J)
- BACnet IP, (Annex J), Foreign Device
- ISO 8802-3, Ethernet (Clause 7)
- ANSI/ATA 878.1, 2.5 Mb. ARCNET (Clause 8)
- ANSI/ATA 878.1, RS-485 ARCNET (Clause 8), baud rate(s)
- MS/TP master (Clause 9), baud rate(s): 76.8k 38.4k, 19.2k, 9600 bps
- MS/TP slave (Clause 9), baud rate(s):
- Point-To-Point, EIA 232 (Clause 10), baud rate(s):
- Point-To-Point, modem, (Clause 10), baud rate(s):
- LonTalk, (Clause 11), medium:
- Other:

Device Address Binding:

Is static device binding supported? (This is currently necessary for two-way communication with MS/TP slaves and certain other devices.) Yes No

Networking Options:

- Router, Clause 6 - List all routing configurations, e.g., ARCNET-Ethernet, Ethernet-MS/TP, etc.
- Annex H, BACnet Tunneling Router over IP
- BACnet/IP Broadcast Management Device (BBMD)

Character Sets Supported:

Indicating support for multiple character sets does not imply that they can all be supported simultaneously.

- ANSI X3.4
- IBM®/Microsoft® DBCS
- ISO 8859-1
- ISO 10646 (UCS-2)
- ISO 10646 (UCS-4)
- JIS C 6226

If this product is a communication gateway, describe the types of non-BACnet® equipment/networks(s) that the gateway supports:

Not Applicable

Model 8636-BAC BACnet® MS/TP Object Set

Object Type	Device Instance	*Units	Description	
Analog Input	1	ft/min, m/s, ”H ₂ O, Pa	Room Pressure	
Analog Input	2	cfm, l/s	Supply Flow Rate	
Analog Input	3	cfm, l/s	Supply Flow Setpoint	
Analog Input	4	°F, °C	Temperature	
Analog Input	5	% Open	Supply Damper Position	
Analog Input	6	% Open	Exhaust Damper Position	
Analog Input	7	% Open	Reheat Valve Position	
Analog Value	1		MAC Address	1 to 127
Analog Value	2	ft/min, m/s, ”H ₂ O, Pa	Room Pressure Setpoint	-0.19500 to 0.19500 ”H ₂ O
Analog Value	3	ft/min, m/s, ”H ₂ O, Pa	Door Pressure Setpoint	-0.19500 to 0.19500 ”H ₂ O
Analog Value	4	ft/min, m/s, ”H ₂ O, Pa	Low Pressure Alarm	-0.19500 to 0.19500 ”H ₂ O
Analog Value	5	ft/min, m/s, ”H ₂ O, Pa	High Pressure Alarm	-0.19500 to 0.19500 ”H ₂ O
Analog Value	6	ft/min, m/s, ”H ₂ O, Pa	Door Low Pressure Alarm	-0.19500 to 0.19500 ”H ₂ O
Analog Value	7	ft/min, m/s, ”H ₂ O, Pa	Door High Pressure Alarm	-0.19500 to 0.19500”H ₂ O
Analog Value	8	cfm, l/s	Vent Min Setpoint	0 to 30,000 cfm
Analog Value	9	cfm, l/s	Cooling Flow Setpoint	0 to 30,000 cfm
Analog Value	10	cfm, l/s	Unocc Flow Setpoint	0 to 30,000 cfm
Analog Value	11	cfm, l/s	Min Supply Alarm	0 to 30,000 cfm
Analog Value	12	°F, °C	Temperature Setpoint	50 to 85 °F
Analog Value	13	°F, °C	Unocc Temp Setpoint	50 to 85 °F
Analog Value	14	% Open	Min Sup Damp Setpoint	0 to 100%
Analog Value	15	% Open	Max Sup Damp Setpoint	0 to 100%
Analog Value	16	% Open	Min Exh Damp Setpoint	0 to 100%
Analog Value	17	% Open	Max Exh Damp Setpoint	0 to 100%
Binary Value	1		Control Mode	0 Normal 1 Door Mode
Binary Value	2		Occ/Unocc Mode	0 Occupied 1 Unoccupied

Object Type	Device Instance	*Units	Description	
Multi-State Input	1		Status Index	1 Normal 2 Low Press Alarm 3 High Press Alarm 4 Min Supply Alarm 5 Data Error 6 Emergency
Multi-State Value	2		Emergency Mode	1 Exit Emergency Mode 2 Enter Emergency Mode 3 Normal
Multi-State Value	3		Units Value	1 ft/min 2 m/s 3 "H ₂ O 4 Pa
Device	863001**		TSI8636	

* The units are based on the value of the Units Value object. When the Units Value is set to 1 or 3 the units are in English form. When the Units Value is set to 2 or 4 the units are metric. English is the default value.

** The device instance is 863000, summed with the MAC address of the device.

(This page intentionally left blank)

Appendix C

Wiring Information

Back Panel Wiring

PIN #	DIM Input / Output / Communication	Description
1, 2	Input	24 VAC to power Digital Interface Module (DIM) and sensor. NOTE: 24 VAC becomes polarized when connected to DIM.
3, 4	Output	24 VAC power for Pressure Sensor
5, 6	Input	0 to 10 VDC pressure sensor signal
7, 8	Communications	RS-485 communications between DIM and pressure sensor
9, 10	Output	0 to 10 VDC general exhaust control signal
11, 12	Input	Non powered switch input - When input is closed these software items are enabled: DOOR LOW ALM, DOOR HIGH ALM, and DOOR DELAY.
13, 14	Output	Alarm relay - N.O., closes in alarm condition. See menu items ALARM & DOOR ALARM
15, 16	Communications	RS-485 communications between DIM and host building automation system.
17, 18	Output	0 to 10 VDC supply air control signal
19, 20	Input	Non powered switch input – When input is closed, this software item is enabled: UNOCC SETP
21, 22	Input	0 to 10 VDC flow station signal - supply duct #1.
23, 24	Input	1000Ω platinum RTD temperature input signal
25, 26	Output	0 to 10 VDC, 4 to 20 mA temperature control signal to reheat valve
27, 28	Input/Communications	0 to 10 VDC flow station signal - supply duct #2. Optional LonWorks® communications to building management system. Optional BACnet® MSTP communications to building management system.

WARNING: The wiring diagram shows polarity on many pairs of pins: + / -, H / N, A / B. Damage to the DIM may occur if polarity is not observed.

NOTE: Terminals 27 & 28 are utilized for LonWorks® communications when the LonWorks® communication board option is included with the controller or BACnet® MSTP communications for Model 8636-BAC.
For Model 8636-BAC or Model 8636-LN, the controller can not accept a second supply flow input; and all second supply flow menu items will be deleted from the menu structure.




Figure 10: Wiring Diagram – Damper Systems, Electric Actuator

Appendix D

Access Codes

This is the access code to all of the menus of the SUREFLOW™ controller. When an access code is required, pressing the following key sequence will provide access to the required menu.

<u>Key #</u>	<u>Setpoints</u>
1	EMERGENCY
2	MUTE
3	MUTE
4	MENU
5	AUX

(This page intentionally left blank)

TSI Incorporated – 500 Cardigan Road, Shoreview, MN 55126 U.S.A

USA	Tel: +1 800 874 2811	E-mail: answers@tsi.com	Website: www.tsi.com
UK	Tel: +44 149 4 459200	E-mail: tsiuk@tsi.com	Website: www.tsiinc.co.uk
France	Tel: +33 491 11 87 64	E-mail: tsifrance@tsi.com	Website: www.tsiinc.fr
Germany	Tel: +49 241 523030	E-mail: tsiqmbh@tsi.com	Website: www.tsiinc.de
India	Tel: +91 80 41132470	E-mail: tsi-india@tsi.com	
China	Tel: +86 10 8251 6588	E-mail: tsibeijing@tsi.com	
Singapore	Tel: +65 6595 6388	E-mail: tsi-singapore@tsi.com	

Contact your local TSI Distributor or visit our website www.tsi.com for more detailed specifications.

